


Mimaki

# JV33-160

# JV33-130

## MAINTENANCE MANUAL

*Revision 1.1*



MIMAKI ENGINEERING CO., LTD.

TKB Gotenyama Building, 5-9-41, Kitashinagawa, Shinagawa-ku, Tokyo 141-0001, Japan

Phone : +81-3-5420-8671 Fax : +81-3-5420-8687

URL : <http://www.mimaki.co.jp/>

D500346-11

**MAINTENANCE MANUAL**

# About this Maintenance Manual

This manual covers the instructions and useful information to be given to the service personnel on maintenance of the color inkjet printer JV33-130/160. Perform maintenance work according to the instructions given in this manual and the related documents listed below.

## Constitution

---

This manual consists of the following chapters:

### CHAPTER 1 Outline of Maintenance

Describes the specifications and other information of the printer, including precautions to be taken in maintenance work.

### CHAPTER 2 Operation Principle and Functions

Explains the operation of each unit, and describes the functions and setting items of the printer.

### CHAPTER 3 Overhaul / Adjustment

Describes procedures for removal and reinstallation of major parts.  
Adjusting or testing methods, or mechanical adjusting methods using jigs and tools are also described.

### CHAPTER 4 Troubleshooting

Describes how to determine the cause of trouble and how to repair the printer.

### CHAPTER 5 Explanation of Electrical Parts

Describes information about PCBs and electrical parts.

## Related Documents

---

The following documents relate to JV33-130/160. Refer to them whenever necessary.

- OPERATION MANUAL (Packed with main unit)
- MECHANICAL DRAWING
- SETUP GUIDE (for Service Engineers)

# Safety Symbols

## Symbols


The following symbols are used in this manual. Understand the symbols, and be sure to observe the instructions.

| In text  | Name of symbol   | Meaning  |
|--|------------------|--|
|   | “WARNING” mark   | Failure to observe the instructions given with this symbol can result in death or serious injuries to personnel.                               |
|   | “CAUTION” mark   | Failure to observe the instructions given with this symbol can result in injuries to personnel or damage to property.                          |
|   | “IMPORTANT” mark | Important notes on maintenance work are given with this symbol. Understand the instructions thoroughly, and perform maintenance work properly. |
|  | “Tips” mark      | Useful information for maintenance work is given with this symbol.   |
| (P.1-10)   | Reference page   | Related description is given on the page shown by this symbol. Be sure to refer to the specified page.   |

## Caution Label

A caution label is stuck on the printer as shown below. Check the label before work. If it is illegible due to stains or coming off, replace it with a new one after getting user's consent.

□ Locations of labels



① (Reorder: M901549)

| ⚠ 注意                  | ⚠ 注意                             | ⚠ CAUTION   | ⚠ ACHTUNG  | ⚠ ATTENTION  |
|-----------------------|----------------------------------|---|--|--|
| 滾輪转动时, 请勿将手插入前面外盖的内部。 | キャリッジ動作中は、フロントカバーの中に指を入れないでください。 | -MOVING CARRIAGE-<br>Do not put fingers inside this area. | -Beweglicher Wagen-<br>Finger nicht in diesen Bereich bringen. | -CHARIOT MOBILE-<br>Ne pas mettre de doigts dans cette zone. |

② (Reorder: M903239)



③ (Reorder: M903330)




④ (Reorder: M903405)



⑤ (Reorder: M904810)



~ Rear ~



---

# Contents

## Outline of Maintenance

---

|   |            |
|---|------------|
| <b>1-1. Precautions in Maintenance</b> .....                | <b>1-2</b> |
| 1-1-1. Notes on repair .....                                | 1-2        |
| 1-1-2. Preliminary checks .....                             | 1-3        |
| <b>1-2. Tools required for maintenance work</b> .....       | <b>1-4</b> |
| 1-2-1. Tools to be used at disassembly and reassembly ..... | 1-4        |
| 1-2-2. Adjustment tools .....                               | 1-4        |
| <b>1-3. Specifications of the main unit</b> .....           | <b>1-5</b> |

## Operation Principle and Functions

---

|   |             |
|---|-------------|
| <b>2-1. Operation Principle</b> .....         | <b>2-2</b>  |
| 2-1-1. Sequence at Power-on .....             | 2-2         |
| 2-1-2. Origin Point Detection .....           | 2-2         |
| 2-1-3. Set Up .....                           | 2-3         |
| 2-1-4. Media Detection .....                  | 2-3         |
| 2-1-5. Sequence of Maintenance Function ..... | 2-4         |
| 2-1-6. Ink System .....                       | 2-7         |
| <b>2-2. Functions</b> .....                   | <b>2-20</b> |
| 2-2-1. ADJUST Function .....                  | 2-20        |
| 2-2-2. TEST Function .....                    | 2-27        |
| 2-2-3. Special Key Function .....             | 2-38        |
| 2-2-4. PARAMETER Function .....               | 2-39        |
| <b>2-3. Operation Flow</b> .....              | <b>2-40</b> |
| 2-3-1. Outline .....                          | 2-40        |
| 2-3-2. SETUP .....                            | 2-41        |
| 2-3-3. MAINTENANCE .....                      | 2-43        |
| 2-3-4. MACHINE SET .....                      | 2-46        |
| 2-3-5. COMMON SETUP .....                     | 2-47        |
| 2-3-6. INFORMATION .....                      | 2-48        |
| 2-3-7. ADJUST .....                           | 2-49        |
| 2-3-8. TEST .....                             | 2-52        |
| 2-3-9. PARAMETER .....                        | 2-56        |

## Overhaul / Adjustment

---

|   |            |
|---|------------|
| <b>3-1. Outline</b> .....                               | <b>3-2</b> |
| 3-1-1. Precautions for disassembly and reassembly ..... | 3-2        |
| 3-1-2. Tools and jigs .....                             | 3-3        |
| <b>3-2. Overhaul of Covers</b> .....                    | <b>3-4</b> |
| <b>3-3. Overhaul of Ink-related Parts</b> .....         | <b>3-6</b> |
| 3-3-1. Head Unit .....                                  | 3-7        |
| 3-3-2. Pump Motor .....                                 | 3-12       |



|   |             |
|---|-------------|
| 3-3-3. Capping Assembly .....                           | 3-13        |
| 3-3-4. Major Parts for Washing Cartridge Assembly ..... | 3-15        |
| <b>3-4. Overhaul of PCBs .....</b>                      | <b>3-18</b> |
| 3-4-1. Main PCB .....                                   | 3-19        |
| 3-4-2. Station PCB .....                                | 3-25        |
| <b>3-5. Overhaul of Sensors .....</b>                   | <b>3-26</b> |
| <b>3-6. Overhaul of Driving Parts .....</b>             | <b>3-27</b> |
| 3-6-1. X-axis Motor .....                               | 3-28        |
| 3-6-2. Y-axis Motor .....                               | 3-31        |
| 3-6-3. Y-axis Drive Pulley .....                        | 3-35        |
| 3-6-4. Y Drive Belt .....                               | 3-39        |
| 3-6-5. Wiper Unit .....                                 | 3-42        |
| <b>3-7. Overhaul of Other Parts .....</b>               | <b>3-44</b> |
| 3-7-1. Cutter Unit Assembly .....                       | 3-45        |
| 3-7-2. Linear scale .....                               | 3-48        |
| 3-7-3. Adjustment of the station height .....           | 3-50        |

## Troubleshooting

---

|   |            |
|---|------------|
| <b>4-1. Outline .....</b>   | <b>4-2</b> |
| 4-1-1. Rough identification of the source of the trouble .....    | 4-2        |
| 4-1-2. Checking procedure .....                                   | 4-2        |
| <b>4-2. Troubles for which error messages are displayed .....</b> | <b>4-4</b> |
| 4-2-1. Error messages and corrective measures .....               | 4-4        |
| 4-2-2. Warning messages and corrective measures .....             | 4-10       |

## Explanation of Electrical Parts

---

|   |             |
|---|-------------|
| <b>5-1. Outline .....</b>                         | <b>5-2</b>  |
| 5-1-1. Operation Explanation .....                | 5-3         |
| 5-1-2. Power Supply .....                         | 5-4         |
| <b>5-2. Circuit Board Specifications .....</b>    | <b>5-6</b>  |
| 5-2-1. Main PCB .....                             | 5-6         |
| 5-2-2. PRAM PCB .....                             | 5-7         |
| 5-2-3. Station PCB .....                          | 5-7         |
| 5-2-4. X-axis motor relay PCB .....               | 5-8         |
| 5-2-5. Ink slider PCB .....                       | 5-9         |
| 5-2-6. Keyboard PCB .....                         | 5-9         |
| 5-2-7. Encoder PCB .....                          | 5-9         |
| 5-2-8. Take-up PCB .....                          | 5-9         |
| 5-2-9. Head memory PCB .....                      | 5-10        |
| 5-2-10. LED PCB .....                             | 5-10        |
| <b>5-3. Electronic block diagram .....</b>        | <b>5-11</b> |
| 5-3-1. Connection diagram inside main unit .....  | 5-11        |
| 5-3-2. Connection diagram outside main unit ..... | 5-13        |

# CHAPTER 1 Outline of Maintenance

---

---

## **Contents**

|   |            |
|---|------------|
| <b>1-1. Precautions in Maintenance .....</b>                | <b>1-2</b> |
| 1-1-1. Notes on repair .....                                | 1-2        |
| 1-1-2. Preliminary checks .....                             | 1-3        |
| <b>1-2. Tools required for maintenance work .....</b>       | <b>1-4</b> |
| 1-2-1. Tools to be used at disassembly and reassembly ..... | 1-4        |
| 1-2-2. Adjustment tools .....                               | 1-4        |
| <b>1-3. Specifications of the main unit .....</b>           | <b>1-5</b> |



## 1-1. Precautions in Maintenance

### 1-1-1. Notes on repair



- Be sure to turn the power off and unplug the power cable from the main body inlet before starting work.
- To prevent the ink from getting into your eyes, be sure to wear safety goggles and gloves when cleaning the print head or replacing the S pump L assembly or if the ink is anticipated to scatter. If the ink sticks to your hand, the skin may be get rough and dry.
- Danger of explosion if battery is incorrectly replaced.  
Replace only with the same or equivalent type recommended by the manufacture.  
Dispose of used batteries according to the manufacturer's instructions.



- Take sufficient care so that leaked ink does not adhere to other parts. Ink droplets attached to FPCs or connectors may cause shortcircuit or a bad electric contact at inserting/removing a damper, thereby the ink discharge trouble or breakage of head/PCB may occur.
- Properly and carefully connect the FFC cable of the ink slider PCB from the main PCB according to the connector number. Failure to do so may cause a breakage of the PCB because of short-circuit of the power supply.
- Pay sufficient attention on arrangement of 2 FFC cables connecting the ink slider PCB to the head. Wrong arrangement of the FFC cables causes short-circuit of the power supply.
- Do not turn off the power during firmware upgrading. Doing so may disable restarting.

Observe the following precautions in maintenance work.

- Be sure to fully understand precautions given in “For safe operation” in the operation manual for the JV33 series.
- Some error conditions observed may be due to misoperation. First judge whether or not the error condition is caused by misoperation.
- Provide adequate space for the maintenance work.
- When performing tests with the electrical circuit box open, be careful not to receive an electric shock from any live part and not to drop screws or any other parts into the circuit box.
- Take care to avoid insufficient insertion or skewed insertion of any connector or FFC.
- Do not touch the FFC directly. Doing so may cause contact failure.
- Move the lever on the FFC connector up or down gently to release or lock the connector, since the lever breaks easily.
- In the case where it is necessary to conduct maintenance works with the power on, carefully observe the movement of the head. (Keep any part of your body away from the moving parts.)
- Shift the media (in the X-direction) and the head (in the Y-direction) using the jog keys. If it is necessary to shift the paper and the head by hand with the power turned off, exercise care to shift them slowly.

- Do not tilt the printer with the ink cartridges filled with ink. Doing so can give rise to leakage of ink. In principle, the following procedures should be taken in prior to the transportation and the transportation should be conducted using exclusive packaging material.
  1. Remove the ink from the tube with MAINTENANCE in [HD.MAINTENANCE]- [DISCHARGE&WASH] or [#ADJUST] - [HEAD WASH].
  2. Remove the cleaner from the tube with MAINTENANCE in [HD.MAINTENANCE] - [MaintWashLiquid] (if this action is not performed in Step 1.)
  3. Detach the waste ink tank.
  4. Fix the head with the head stopper. (As for the detail, see Setup Guide)
- If the main unit is removed from the legs and placed directly on the floor, be careful of the following points.
  - Unplug the take-up unit power cord.
  - Remove the ink waste tank and the fitting bracket.  
(Plug the tube up with a cloth to prevent ink from spilling over.)

## 1-1-2. Preliminary checks

Before starting work, make sure that the following conditions are all met.

- The following conditions for the power supply system are all met:
  - The power supply voltage must be within the specification limits.
  - The printer must be grounded properly.
  - The power cable must be free from damage, broken wire, etc. Many cables must not be connected to one outlet.
  - Connected to an electrical outlet with a removable plug in cases where smoke or flame has been emitted from the socket.
- Make sure that the printer is not located under any of the following conditions:
  - In a place where the printer is exposed to direct sunlight.
  - On an inclined surface.
  - In an environment of too high or low temperature, or too high or low humidity, or in a place where temperature or humidity varies significantly.
  - In a place where vibration occurs.
  - In a place where the printer is exposed to direct air flow from an air conditioner or the like.
  - Around a place where flame is used.
  - In a dusty atmosphere.
  - Around a place where strong electromagnetic waves are generated.
- The media (sheets) to be used must conform to the specifications.

## 1-2. Tools required for maintenance work

The tables below show the tools and measuring instruments required for maintenance work.

### 1-2-1. Tools to be used at disassembly and reassembly

| Name                   | Remarks   |
|------------------------|---|
| Phillips screwdriver   | Type 1 For M2<br>Type 2 For M3 to 5 (L=260 or more)<br>Type 2 for M3 to 5   |
| Slotted screwdriver    | Long side 2.5 mm for removing E-rings   |
| Spanner (Box wrench)   | Width across flats: 5 mm<br>Width across flats: 5.5 mm<br>Width across flats: 7 mm  |
| Hexagon wrench         | 1.5mm for M3 SSWP<br>2.0mm for M4 SSWP<br>2.5mm for M3 cap bolts<br>5.0mm for M6 cap bolts<br>6.0mm for M8 cap bolts            |
| Spanner                | Width across flats: 5.0 mm<br>Width across flats: 5.5 mm for M3 nuts and hexagon stud<br>Width across flats: 7.0 mm for M4 nuts |
| Tweezers               | To prevent the cable from being pulled when disconnecting the connector.  |
| Long-nose pliers       |   |
| Nippers                |   |
| Soldering iron, Solder |   |
| Scale                  | 150, 500 mm   |
| Loupe                  | About 50x to 60x magnification  |
| Protection glasses     |   |
| Gloves                 | To keep hands clean, and for safety.  |
| Adhesive agent         | LOCKTITE242 (for locking screws)  |
| Insulation lock        | L=150 or less (UL-approved product)   |

### 1-2-2. Adjustment tools

| Name                           | Code      | Remarks   |
|--------------------------------|-----------|---|
| Trimmer adjustment screwdriver |           | For adjustment of trimmers on the power supply PCB. |
| Tester                         |           |   |
| Bar type tension gauge         |           | 500 g   |
| Ink line airtight tester       | OPT-J0094 |   |

# 1-3. Specifications of the main unit

## □ Basic Specifications of the Unit

| Item                        | Specifications   |  | Notice   |   |
|-----------------------------|--|--|--|---|
|                             | JV33-130   | JV33-160   |  |   |
| Head                        | On demand piezoelectric head (IH47V*1 head stagger array)  |  | Solvent capable head   |   |
| Printing resolution         | 540, 720, 1440 dpi   |  | Variable dot capable   |   |
| Print mode<br>(Scan x Feed) | 720 x 540dpi VD:<br>540 or 720 x 720dpi VD :<br>540 x 900dpi VD :<br>540 or 720 x 1080dpi VD :<br>720 x 1440dpi VD :<br>1440 x 1440dpi :   |  | In the following case, fewer nozzles are used for printing due to memory restrictions:<br>4-color : 1440 x 1440dpiVD<br>6-color : 720 x 1440dpiVD<br>1440 x 1440dpiALL<br>6-color + white : 540 x 1080dpi VD<br>720 x 1080dpi VD<br>720 x 1440dpi VD<br>1440 x 1440dpi ALL |   |
| Ink                         | 6-color + white loading<br>(SS21 ink only)   | K • M • C • Y • Lc • Lm • W • W  | Total 8 IC chip mounted cartridges   |   |
|                             | 6-color loading  | K • M • C • Y • Lc • Lm/K • M • BI • Y • LBI • Lm  |  |   |
|                             | 4-color loading  | K • M • C • Y/K • M • BI • Y   |  |   |
| Ink supply                  | (4-color only)Supplying by 2 cartridges with toggle switching (replacement of cartridges at printing is allowed)<br>Ink end is detected with the cartridge end board detection method. |  |  |   |
| Ink capacity                | 6-color + white loading  | White : 2 x 220 cc cartridges<br>Except for white: 1 x 440 cc cartridge of each color  |  |   |
|                             | 6-color loading  | 1 cartridges of 440cc for each color. 440cc/1color   | At 6-color, 880cc for only CM  |   |
|                             | 4-color loading  | 2 cartridges of 440cc for each color. 880cc/1 color  |  |   |
| Available media             | FF, Tarpaulin, Polyvinyl chloride film<br>(However, drying of the media must be allowed in the specified print mode.)  |  | Print quality confirmation media is MIMAKI genuine.  |   |
| Maximum drawing range       | At standard scan   | 1361 mm  | 1610 mm  | When left and right drawing margin is set to the minimum.   |
| Media specification         | Maximum width  | 1371 mm  | 1620 mm  |   |
|                             | Minimum width  | 210 mm   |  |   |
|                             | Thickness  | Less than 1.0 mm   |  |   |
|                             | Roll O.D.  | Less than ø180 mm  |  |   |
|                             | Roll weight  | Less than 25 kg<br>(In the range that feeding error caused by bending with its own weight when both ends of the roll are held does not occur.) |  |   |
|                             | Tube I.D.  | 2 inches, 3 inches   |  |   |
|                             | Drawing face   | Outside (over wrap)  |  |   |
|                             | End of winding   | Taping or weak pasting to the paper tube   |  |   |
|                             | Maximum winding O.D.   | ø180 mm or less  |  |   |
| Print margin                | Roll   | Left and Right: 15 mm (default value)<br>Top : 40.0 mm<br>Bottom: 0.0 mm   |  | Margin of left and right whose tolerance excluding meandering of media is ± 2mm can be changed.                                 |
|                             | Leaf   | Left and Right : 15 mm (default value)<br>Top : 40.0 mm<br>Bottom : 98.5 mm  |  | Minimum 5mm   |
| Distance accuracy           | Precision  | ± 0.3 mm or ± 0.3% of specified distance, whichever larger   |  | Expansion and contraction of test media, photo paper or gloss paper is excluded. Meandering just after the setting is excluded. |
|                             | Repeatability  | ± 0.2 mm or ± 0.1% of specified distance, whichever larger   |  |   |



| Item                        | Specifications  |   | Notice   |
|-----------------------------|---|---|--|
|                             | JV33-130  | JV33-160  |  |
| Perpendicularity            | ± 0.5 mm/1000 mm  |   |  |
| Media skew                  | 5 mm or less /10 m  |   |  |
| Print gap                   | 2.0 mm or 3.0 mm (from the platen surface). 2 level adjustment.   |   |  |
| Media heater                | PRE/PRINT/AFTER (3-system independent control)  |   |  |
| Media cutting               | Cutting in the Y direction with a tool on the head<br>Cutting accuracy (step height) less than 0.5mm                        |   | Cutting tool is a consumable                             |
| Waste ink tank              | Bottle type (2000cc)  |   |  |
| Interface                   | Standard equipment  | USB2.0  | *Cables are maintenance supplies.                        |
| Command                     | MRL-III   |   |  |
| Noise                       | At standby  | Less than 58dB (FAST-A, back and forth and around 1m) |  |
|                             | Continuous  | Less than 65dB  |  |
|                             | Temporal  | Less than 70dB  |  |
| Compatible specification    | VCCI Class A<br>FCC Class A<br>UL 60950<br>CE Marking (EMC Directive, Low Voltage Directive)<br>CB Report<br>RoHS Compliant |   |  |
| Power source specifications | Single-phase AC 100V ~ 120V ± 10%, 220V ~ 240V ± 10%<br>Lower than 15A 50/60Hz ± 1Hz  |   | With the sleep function                                  |
| Power consumption           | Lower than 1440VA   |   | Main body including heater<br>Excluding optional devices |
| Environment                 | Operating temperature limit   | 20 °C~35 °C   |  |
|                             | Relative humidity   | 35~65%Rh (non condensing)                             |  |
|                             | Accuracy assurance temperature  | 20 °C~25 °C   |  |
|                             | Temperature gradient  | Less than ± 10 °C/h                                   |  |
|                             | Dust  | Equivalent to office environment                      |  |
| Weight                      | Main body   | Less than 145 kg                                      | Less than 160 kg   |
| Outside dimension           | (W)   | 2289 mm   | 2538 mm  |
|                             | (D)   | 739 mm  | 739 mm   |
|                             | (H)   | 1424 mm   | 1424 mm  |

# CHAPTER 2 Operation Principle and Functions

---

---

## Contents

|   |             |
|---|-------------|
| <b>2-1. Operation Principle</b> .....         | <b>2-2</b>  |
| 2-1-1. Sequence at Power-on .....             | 2-2         |
| 2-1-2. Origin Point Detection .....           | 2-2         |
| 2-1-3. Set Up .....                           | 2-3         |
| 2-1-4. Media Detection .....                  | 2-3         |
| 2-1-5. Sequence of Maintenance Function ..... | 2-4         |
| 2-1-6. Ink System .....                       | 2-7         |
| <b>2-2. Functions</b> .....                   | <b>2-20</b> |
| 2-2-1. ADJUST Function .....                  | 2-20        |
| 2-2-2. TEST Function .....                    | 2-27        |
| 2-2-3. Special Key Function .....             | 2-38        |
| 2-2-4. PARAMETER Function .....               | 2-39        |
| <b>2-3. Operation Flow</b> .....              | <b>2-40</b> |
| 2-3-1. Outline .....                          | 2-40        |
| 2-3-2. SETUP .....                            | 2-41        |
| 2-3-3. MAINTENANCE .....                      | 2-43        |
| 2-3-4. MACHINE SET .....                      | 2-46        |
| 2-3-5. COMMON SETUP .....                     | 2-47        |
| 2-3-6. INFORMATION .....                      | 2-48        |
| 2-3-7. ADJUST .....                           | 2-49        |
| 2-3-8. TEST .....                             | 2-52        |
| 2-3-9. PARAMETER .....                        | 2-56        |



## 2-1. Operation Principle

### 2-1-1. Sequence at Power-on

The following is the sequence after power-on.

| No. | Item                           | Process content   |
|-----|--------------------------------|---|
| 1   | Initial setting of CPU and H/W |   |
| 2   | BOOT display                   |   |
| 3   | SD-RAM check                   | R/W check of SD-RAM<br>When an error is detected, the system is brought down with displaying ERROR02 (MAIN RAM)   |
| 4   | F-ROM check                    | Hashing check of F-ROM<br><At occurrence of hashing error><br><ul style="list-style-type: none"> <li>■ Occurrence in boot system area:<br/>The system is brought down with displaying ERROR01 (MAIN ROM).</li> <li>■ Occurrence in main system area:<br/>F/W update mode ( See <a href="#">Special Key Function (p. 2-38)</a> ) starts.</li> </ul>  |
| 5   | Voltage check                  | Voltage check<br>When an error is detected, the system is brought down with displaying ERROR03.   |
| 6   | FPGA configuration             | Configuration of PDC and HDC.   |
| 7   | Device configuration decision  | Checking of a head and memory   |
| 8   | Version information display    | Machine type name and main body F/W version are displayed.<br>At a maintenance open, revision and PDC/HDC version are also displayed.<br>Key input during the version information displaying starts special mode ( See <a href="#">Special Key Function (p. 2-38)</a> ).  |
| 9   | Parameter check                | Parameter initialization at the first starting after F/W version-up.<br>(The flowing parameters are initialized.)<br><ul style="list-style-type: none"> <li>■ MAINTE.</li> <li>■ INKSYSTEM</li> <li>■ INKInfor.</li> <li>■ INKSEQUENCE</li> <li>■ INKTYPE</li> <li>■ SERVO</li> <li>■ TEST</li> </ul> Checksum of parameter area is executed, ERROR04 (Flash ROM) is displayed and indicates that the system is down. |
| 10  | Initial operation              |   |

### 2-1-2. Origin Point Detection

Detection of each original point of the device

<Operation sequence at original point detection>

| No. | Item                 | Content   | Notice   |
|-----|----------------------|---|--|
| 1   | Wiper original point | Wiper original point detection (wiper motor drive)<br>If the detection fails, the system is brought to down (ERROR46) | If an error occurs in each original point detection at maintenance open, inputting of <b>[ENTER]</b> causes retry operation. Also, FUNCTION features can be operated. ( <b>[FUNCTION]</b> effective) |
| 2   | Y-original point *   | Y-original point detection (Y-axis motor drive)<br>If the detection fails, the system is brought to down.(ERROR51)    |  |
| 3   | Cap                  | Returning the carriage to the Y-original point.   |  |

\* Retry operation is not conducted even at the Maintenance Open.

## 2-1-3. Set Up

### Machine Configuration

The following required resources are checked.

<Model determination>

| No. | Item                          | Content   |
|-----|-------------------------------|---|
| 1   | HDC connection determination  | When configuration of HDC is not completed, a HDC error (ERROR09) is displayed and the system is brought to down. |
| 2   | Head connection determination | An effective head connection is determined.   |
| 3   | Head memory check             | Determines the head connection.   |
| 4   | SDRAM check                   | If size of SDRAM is 0, ERROR203 (SD-RAM size) is displayed and the system is brought to down.                     |



<Required SDRAM size>  
128 MB

## 2-1-4. Media Detection

Media width and media thickness are detected.

<Media detection operation sequence>

| No. | Item                      | Content   | Notice                              |
|-----|---------------------------|---|-------------------------------------|
| 1   | Media right end detection | After moving the carriage to the media detection position, media right end is detected. (media sensor)  | Up the lever to stop the detection. |
| 2   | Media left end detection  | <ol style="list-style-type: none"> <li>1. After moving the carriage, media left end is detected. (media sensor)</li> <li>2. After measuring the distance between the left end and the right end, media width is calculated (linear encoder)</li> </ol> <p><b>* During carriage moving of the media width detection, the linear encoder is tested.</b><br/> <b>If an error is detected, drawing is disabled. (ERROR8)</b></p> <p>[ERROR8 detailed information]<br/>                     DIRECTION: ± of counter of the linear encoder is wrong<br/>                     COUNT: Count number of the linear encoder is error<br/>                     SENSOR: Count failure</p> <p><b>* When the media width can not be detected, ERROR50.</b><br/>                     (Up the lever to release)</p> <p>Returning the carriage to the Y-original point and cap ON.</p> <p>* Distance accuracy adjusting is automatically executed in the media detection.</p> | Up the lever to stop the detection. |
| 3   | Media length inputting    | When "MEDIA RESIDUAL" of the MAINTENANCE function is set to ON and media return end detection failed, input media length.<br>Set value: 1 ~ 500m (unit:1m)  |                                     |

## 2-1-5. Sequence of Maintenance Function

### □ CARRIDGE OUT

#### <CARRIDGE OUT operation sequence>

| No. | Item        | Content   | Notice |
|-----|-------------|---|--------|
| 1   | Start       | 1. Cap OFF<br>2. After moving the carriage to the maintenance position, wiper-ON and servo motor-OFF. |        |
| 2   | Maintenance | No action during the maintenance.<br>(Waiting for inputting <b>[ENTER]</b> of maintenance end.)       |        |
| 3   | End         | Wiper-OFF and after moving the carriage, initial operation (origin point detection)                   |        |

Note : In order to avoid dehydration of nozzle surface and inside of the cap, a warning beep is made every 30 seconds.  
(Only at maintenance closing)

### □ WIPER EXCHANGE

#### <WIPER EXCHANGE operation sequence>

| No. | Item          | Content   | Notice |
|-----|---------------|---|--------|
| 1   | Start         | 1. Cap OFF<br>2. After moving the carriage to the maintenance position, wiper-ON and servo motor-OFF. |        |
| 2   | Maintenance 2 | No action during the maintenance.<br>(Waiting for inputting <b>[ENTER]</b> of maintenance end.)       |        |
| 3   | End           | Wiper-OFF and after moving the carriage, initial operation (origin point detection)                   |        |

Note : After finishing, wiping execution number of times of running parameter is cleared.  
In order to avoid dehydration of nozzle surface and inside of the cap, a warning beep is made every 30 seconds.  
(Only at maintenance closing)

### □ NOZZLE WASH

#### <NOZZLE WASH operation sequence>

| No. | Item                      | Operation content  | Notice |
|-----|---------------------------|--|--------|
| 1   | Start                     | 1. Cap OFF<br>2. After moving the carriage to the maintenance position, wiper-ON and servo motor-OFF.<br>3. Pump tube is locked.   |        |
| 2   | Maintenance (Wiper)       | No action during the wiper cleaning.<br>(Waiting for inputting <b>[ENTER]</b> of wiper cleaning end.)  |        |
| 3   | Maintenance (Nozzle wash) | 1. Wiper OFF<br>2. The pump tube is locked and a message of "Fill the liquid." is displayed. (Waiting for inputting of <b>[ENTER]</b> ).<br>3. Input "being left time". (Waiting for inputting <b>[ENTER]</b> )<br>Set value: 1 ~ 99 min (time unit: 1 min)<br>4. After moving the carriage and initial operation (original point detection), no action for designated time. |        |
| 4   | Maintenance (End)         | 1. Execution of cleaning.<br>2. End  |        |

Note : In order to avoid dehydration of nozzle surface and inside of the cap, a warning beep is made every 30 seconds.  
(Only at maintenance closing)

**□ PUMP TUBE WASH**

Cleaning of ink discharge path. Operation sequence is as the following.

**<PUMP TUBE WASH cleaning operation sequence>**

| No. | Item                      | Operation content   | Notice  |
|-----|---------------------------|---|---|
| 1   | Start                     | 1. Cap OFF<br>2. Moving the carriage to the maintenance position, wiper ON, servo motor OFF.  |   |
| 2   | Maintenance (Nozzle wash) | The following operations are repeated until [ENTER] is input.<br>1. Pump tube lock<br>2. 10 seconds No action<br>3. 5 seconds dry suction | Cleaner is injected into the cap when you press the [FUNCTION] key. |
| 3   | End                       | 1. 20 seconds dry suction<br>2. Execution of initial operation (original position detection)  |   |

Note : In order to avoid dehydration of nozzle surface and inside of the cap, a warning beep is made every 30 seconds. (Only at maintenance closing)

**CR.MAINTENANCE**

Execution of carriage maintenance (cleaning in the vicinity of head)

**<CR.MAINTENANCE operation sequence>**

| No. | Item        | Content  | Notice |
|-----|-------------|--|--------|
| 1   | Start       | 1. Cap OFF<br>2. Move the carriage to the maintenance position in the left end, servo motor OFF. |        |
| 2   | Maintenance | No action during the maintenance.<br>(Waiting for inputting [ENTER] of maintenance end.)         |        |
| 3   | End         | Move the carriage, and execute initial operation (original position detection)                   |        |

Note : In order to avoid dehydration of nozzle surface and inside of the cap, a warning beep is made every 30 seconds. (Only at maintenance closing)

**HD.MAINTENANCE**

The following maintenance items of head are executed.

**□ FILL UP INK**

Select a head to fill ink

**<FILL UP INK operation sequence>**

| No. | Item    | Content   | Notice  |
|-----|---------|---|---|
| 1   | Start   | When a waste ink tank warning occurs, a warning is displayed. As for the detail of “About the waste ink tank warning” (p. 2-6).               |   |
| 2   | Filling | Open cartridge valve and drive ink suction motor.<br>The operation is stopped when a warning is detected in ink cartridge during the filling. | Use a cartridge having smaller residual ink quantity. (4-color UISS only) |
| 3   | End     | Stop the pump motor.  |   |

## □ DISCHARGE&WASH

Ink in head, damper and tube is discharged to execute cleaning.

### <DISCHARGE&WASH operation sequence>

| No. | Item   | Operation content   | Notice                     |
|-----|--|---|----------------------------|
| 1   | Ink discharging  | 1. Taking out cartridges (all slots) (Cartridge sensor monitoring)<br>2. Discharging ink (Ink suction motor driving)<br>As for the detail of “About the waste ink tank warning” (p. 2-6).   | Cartridge valve is closed. |
| 2   | Washing  | 1. Inserting washing solution cartridges (all slots)<br>(Cartridge sensor monitoring* <sup>1</sup> )<br>2. Cleaning inside of tube.<br>(Opening cartridge valve, ink suction motor driving)<br>As for the detail of “About the waste ink tank warning” (p. 2-6).<br>3. Head vibrating operation (Y-axis motor) is executed. |                            |
| 3   | Discharging of washing solution                        | 1. Taking out washing solution cartridges (all slots).<br>(Cartridge sensor monitoring)<br>2. Discharging washing solution (ink suction pump motor driving)<br>As for the detail of “About the waste ink tank warning” (p. 2-6).  | Cartridge valve is closed. |
| 4   | Repeating  | 3~4 are executed again.   |                            |
| 5   | Operation selection                                    | [▶] Re-Wash : No.3 →4 are executed again<br>[◀] COMPLETED : (to next No.)   |                            |
| 6   | Confirmation of maintenance washing solution discharge | [◀] No : to No.9 (End)<br>[▶] DISCHARGE : (to next No.)   |                            |
| 7   | Maintenance washing solution discharge                 | See the next item, “Maintenance washing solution fill/discharge operation sequence”   |                            |
| 8   | End  | (When cleaning is executed, the state is Not-filling at discharging ink.)   |                            |

\*1 As an IC chip is not placed in a pre-fill up solution cartridge, it is recognized that IC chip read error means normal.

## □ Washing solution/fill up/discharge

Dedicated washing solution for PUMP TUBE WASH is filled.

### <Washing solution filling operation sequence>

| No. | Item    | Operation content  | Notice                  |
|-----|---------|--|-------------------------|
| 1   | Start   | Washing solution suction (ink suction motor driving)<br>If a warning arises in the washing solution cartridge, filling is not executed.<br>As for the detail of “About the waste ink tank warning” (p. 2-6). | Waste ink tank cleaning |
| 2   | Filling | 1. Run the pump.<br>2. Cartridge valve open.<br>(until washing solution is filled in the wiper cleaning valve)<br>3. Cartridge valve close.<br>4. Pump stop.   |                         |

Note: At discharging

1. Remove a cartridge
2. Run the ink/suction pump, and eject the ink.

At filling

1. Set a cartridge
2. Run the ink/suction pump, and fill with ink.

## □ About the waste ink tank warning

The amount of ink discharged is monitored by the counter in the firmware, and depending on the situation, before operations involving suction (cleaning, filling, and discharge), a prompt to replace the waste ink tank may be displayed.

When reached to near full: The options “CONTINUE” and “EXCHANGE” is displayed.

When reached to full: Only the option “EXCHANGE” is displayed.

- When “CONTINUE” is selected: The operation continues.  
The warning is displayed again at the next suction operation.  
(The counter value is not cleared.)
- When “EXCHANGE” is selected: Replace or empty the waste ink tank.  
The operation continues.  
(The counter value is cleared.)

When “!WASTE TANK” is displayed locally:

Displayed when the internal counter is at near full or higher. When it is displayed, sleep and regular operations (refresh, pump tube washing, cleaning) are not performed. When you cancel the warning message, be sure to replace the waste ink tank, then execute [MAINTENANCE] - [InkTankExchange] (clear internal counter).

## 2-1-6. Ink System

### Ink Supply Control

- Ink filling method of JV33 is a suction system with roller pump, a pressure damper with a self sealing valve is used. Ink supply at drawing is a siphon supply. The sealing valve is opened by discharging pressure reduction to supply ink, and when the damper ink chamber is filled, the sealing valve is closed. The ink path pressure at carriage moving conveyed to the meniscus of head is eased by the sealing valve.
- Longer consecutive drawing time than conventional products and replacement of cartridges during the drawing are allowed by toggle switching of 2 cartridges for 1 supply path (4-color only). Since there is 1 path per cartridge for except for 4-color, replacement during use is not possible.
- During the ink end cartridge replacement, in order to avoid dehydration of ink supply system, a WARNING is displayed if a cartridge is not placed for more than 10 minutes.
- A supply valve is placed for each cartridge to supply ink at the supply valve OPEN. The supply valve is usually in CLOSE state, and when ink supply is necessary, the supply valve turns to OPEN state. Ink supply is conducted at discharging operation (drawing and flashing) and suction operation (cleaning and filling). The supply valve is not opened for a cartridge having an error not to supply ink.
- 2 types of LED (Green: control LED / Red: Error LED) are placed for each cartridge to allow a user to check a state of cartridge in visual. Since all 8 cartridges for except for 4-color are control cartridges, the green LED is on for cartridges where there is no error.
- JV33 switches the supply valve at occurrence of “INK NEAR END” or “INK END” in the cleaning to use a cartridge having smaller residual quantity. As for details, see “ [Ink wear-up cleaning \(4-color only\)](#)” (P.2-16). (4-color only)

### Device configuration

The device configuration of ink supply path is shown below.

The firmware switches select whether the inkset configured at the initial filling is 4-color or not.

□ 4-color filling

2 paths of the same color are linked directly after the cartridge valve. Normally the valve of 1 cartridge per color is opened by toggle switching, supplying ink to a 2-nozzle row. Thereafter, the cartridge on the side with the open valve is referred to as the control cartridge, while the other is referred to as the sub cartridge.




Fig.2-1 Ink Supply Path Diagrammatic Illustration (4-Color Filling)

□ Except for 4-color filling

Since 1 cartridge is linked to 1 nozzle, toggle switching is not used, and all cartridges are control cartridges.




Fig.2-2 Ink Supply Path Diagrammatic Illustration (6-Color Filling)




Fig.2-3 Ink Supply Path Diagrammatic Illustration (6-Color+white Filling) \*Only when loaded with SS21

## Flow of the ink supply control

The ink supply control flow can be divided as the followings.

1. Error check of the cartridge.
2. Selection/determination of a supply cartridge (depends on a state of the cartridge). (4-color only)  
(Except for 4-color, all cartridges are supply cartridges.)
3. Updating of each LED (depends on a state of the supply/error cartridge).
4. Supply valve open/close operation of the cartridge selected in "2" with a valve operation instruction.

### □ Error check of a cartridge

The error check of a cartridge is executed periodically (every 30 ms) to select a supply cartridge according to an error state and ink residual quantity.

The supply cartridge notifies being under control with lighting the control LED (Green).

The error cartridge lights/blink the error LED (Red) to urge replacement of cartridges.

A valve of the cartridge indicated by lighting of the control LED is opened with a valve-open instruction.

When an error occurs in a supply cartridge while the valve is opened (at drawing or at cleaning), if there is a cartridge which can supply ink, the valve is switched to continue the operation, if a supply cartridge is removed, drawing is aborted and cleaning is terminated to return to the local state.

Since all 8 cartridges for except for 4-color are supply cartridges, when an error occurs, plotting stops, cleaning finishes, and the status returns to local.

### □ Selection/determination of a supply cartridge (4-color only)

As ink is supplied by toggle switching of 2 cartridges for 1 supply path in JV33, a supply cartridge should be selected. The followings are selection conditions of a supply cartridge.

Since all 8 cartridges for 6-color are supply cartridges, switching is not used.

#### a) When there is a cartridge having an error in 1 supply path.

- If another cartridge can supply, the cartridge is selected.
- The selection conditions depend on occurrence of an error, contents of the error and ink supply timing. The ink supply is executed at discharging operation (drawing, flushing and so on) or at suction operation (cleaning and filling).

The followings are cartridge selection conditions. As for errors, see "[Ink system error monitoring](#)" (P.2-14).

#### <Cartridge selection conditions>

| Error content                 | Discharging operation | Suction operation |
|-------------------------------|-----------------------|-------------------|
| Normal cartridge              | ○                     | ○                 |
| Cartridge near end            | ○                     | △                 |
| Cartridge ink end             | ×                     | △                 |
| Residual quantity 0 cartridge | ×                     | ×                 |
| No cartridge                  | ×                     | ×                 |
| InK IC *                      | ×                     | ×                 |

Note ○: Supply is effective.

△: Supply is effective when another cartridge is normal.

×: Supply is not effective

\* Ink IC: NON-ORIGINAL INK, WRONG INK IC, Kind of INK, Color of INK, WRONG CARTRIDGE, Expiration:2MONTH

**b) When there are plural of effective cartridges in 1 supply path.**

| Priority | Content   |
|----------|---|
| 1        | A cartridge having smaller ink residual quantity.                           |
| 2        | When “1” is the same, a cartridge having closer expiration date.            |
| 3        | When both “1” and “2” are the same, a cartridge having smaller slot number. |

Occurrence timing of supply cartridge switching

- At power-on
- When an error occurs in the currently selected cartridge.
- When a cartridge superior to the currently selected cartridge is inserted.  
(Switching is not executed at drawing or cleaning. It is executed when returned to the local state.)

Based on a) and b), effectiveness of ink supply in variety of cartridge states is shown in the table below.

**<Ink supply effectiveness>**

| Cartridge 1                   | Cartridge 2 | Normal cartridge | Cartridge near end | Cartridge ink end | Residual quantity 0 cartridge | No cartridge | Ink IC |
|-------------------------------|-------------|------------------|--------------------|-------------------|-------------------------------|--------------|--------|
| Normal cartridge              |             | ○                | ○                  | ○                 | ○                             | ○            | ○      |
| Cartridge near end            |             | ○                | △                  | △                 | △                             | △            | △      |
| Cartridge ink end             |             | ○                | △                  | ×                 | ×                             | ×            | ×      |
| Residual quantity 0 cartridge |             | ○                | △                  | ×                 | ×                             | ×            | ×      |
| No cartridge                  |             | ○                | △                  | ×                 | ×                             | ×            | ×      |
| Ink IC                        |             | ○                | △                  | ×                 | ×                             | ×            | ×      |

Note ○: Discharge is allowed and suction is allowed.  
 △: Discharge is allowed and suction is not allowed (Near end error).  
 ×: Discharge is not allowed and suction is not allowed (Ink end error). As for details, see “[Ink system error monitoring](#)” (P.2-14).

The table below shows the switching timing of supply cartridges.

**<Conditions for supply cartridge switching timing> Active side: Cartridge which is selected now**

| Active                        | Non-active | Normal cartridge | Cartridge near end | Cartridge ink end | Residual quantity 0 cartridge | No cartridge | Ink IC |
|-------------------------------|------------|------------------|--------------------|-------------------|-------------------------------|--------------|--------|
| Normal cartridge              |            | △                | ○                  | -                 | -                             | -            | -      |
| Cartridge near end            |            | -                | △                  | -                 | -                             | -            | -      |
| Cartridge ink end             |            | ○                | ○                  | -                 | -                             | -            | -      |
| Residual quantity 0 cartridge |            | ○                | ○                  | -                 | -                             | -            | -      |
| No cartridge                  |            | ○                | ○                  | -                 | -                             | -            | -      |
| Ink IC                        |            | ○                | ○                  | -                 | -                             | -            | -      |

Note ○: Switch  
 △: Switch according to the condition of priority.  
 -: Not switched  
 During the cleaning an operation may not follow the conditions above. As for details, see “[Ink wear-up cleaning \(4-color only\)](#)” (P.2-16).

**□ Cartridge LED**

Lighting/blinking of 2 types of LED informs cartridge states to show the timing of replacement.

When the Control LED (Green) lights : At supplying

When the Error LED (Red) lights/blinks : Occurrence of an error

Lighting/blinking conditions for each LED are shown in the table below.

**<Conditions for lighting/blinking of LED>**

| LED                 |           | State  |
|---------------------|-----------|--|
| Control LED (Green) | Not light | Supply cartridge is not selected   |
|                     | Blinking  | –  |
|                     | Light     | <ul style="list-style-type: none"> <li>■ At selecting a supply cartridge (Except for 4-color, the LEDs for all are ON unless an error has occurred.)</li> <li>■ At ink wear-up cleaning (See “<a href="#">Ink wear-up cleaning (4-color only)</a>” (P.2-16)) (4-color only)</li> </ul> |
| Error LED (Red)     | Not light | At normal state  |
|                     | Blinking  | Occurrence of an error (Blinks at occurrence of the following errors). <ul style="list-style-type: none"> <li>■ Cartridge near end</li> <li>■ Cartridge ink end</li> <li>■ 1 months passed after ink expiration date</li> </ul>  |
|                     | Light     | Occurrence of an error (Lights at occurrence of the following errors) <ul style="list-style-type: none"> <li>■ Residual quantity 0 cartridge</li> <li>■ No cartridge</li> <li>■ Ink IC*</li> </ul>   |

\* Ink IC: NON-ORIGINAL INK, WRONG INK IC, Kind of INK, Color of INK, WRONG CARTRIDGE, Expiration:2MONTH

Examples of cartridge switching and LED operation patterns are shown in the table below.

**<LED operation pattern>**

| Event  | Valve operation         | 4-color     |           |             |           | Except for 4-color |           |
|--|-------------------------|-------------|-----------|-------------|-----------|--------------------|-----------|
|  |                         | Cartridge 1 |           | Cartridge 2 |           | Cartridge 1        |           |
|  |                         | Control LED | Error LED | Control LED | Error LED | Control LED        | Error LED |
| Online drawing start<br>No problem on both cartridge | Cartridge 1 valve open  | Light       | –         | –           | –         | Light              | –         |
| Cartridge 1<br>Cartridge near end occurs             | Not changed             | Light       | Blink     | –           | –         | Light              | Blink     |
| Cartridge 1<br>Cartridge ink end occurs              | Switched to cartridge 2 | –           | Blink     | Light       | –         | –                  | Blink     |
| Cartridge 2<br>Cartridge near end occurs             | Not changed             | –           | Blink     | Light       | Blink     |                    |           |
| Cartridge 1<br>Take out to replace                   | Not changed             | –           | Light     | Light       | Blink     | –                  | Light     |
| Cartridge 1<br>Set a normal cartridge                | Not changed             | –           | –         | Light       | Blink     | Light              | –         |
| Cartridge 2<br>Cartridge ink end occurs              | Switched to cartridge 1 | Light       | –         | –           | Blink     |                    |           |
| Online drawing end                                   | Close all supply valves | Light       | –         | –           | Blink     | Light              | –         |

**Open/close instruction for supply valve**

Generally, a supply valve is in the CLOSE state, and OPEN is instructed when ink supply is necessary. Timing of open/close instruction is shown in the table below.

<Supply valve operation instruction timing>

| Timing  |                  | Supply valve operation instruction |       |
|---|------------------|------------------------------------|-------|
|   |                  | OPEN                               | CLOSE |
| Flushing  | Before execution | ○                                  | –     |
|   | After execution  | –                                  | ○     |
| Cleaning/filling                                      | Before execution | ○                                  | –     |
|   | After execution  | –                                  | ○     |
| Wash  | Before execution | ○                                  | –     |
|   | After execution  | –                                  | ○     |
| Before drawing operation                              |                  | ○                                  | –     |
| Before Capping  |                  | –                                  | ○     |
| Replacement of supply cartridges during ink supplying |                  | ○                                  | ○     |
| At occurrence of an system error                      |                  | –                                  | ○     |
| At power-off  |                  | –                                  | ○     |

Note ○: Operation instruction

**Cartridge Control**

For 4-color

2 ink cartridges are used per 1 supply system (1 nozzle row), total 8 cartridges can be loaded. Supply cartridge is always 1 per 1 supply system, and a cartridge having smaller residual quantity is used first with toggle switching. LED (Green, Red) of each slot indicates cartridge states shown below.

Except for 4-color (6-color or 6-color + white filling)

Since there is 1 ink cartridge per supply system, all 8 cartridges are supply cartridges.

<Cartridge states indicated by LED>

|           |       |   |
|-----------|-------|---|
| Green LED | Light | Supply cartridge  |
| Red LED   | Blink | INK END, INK NEAR END, Expiration:1MONTH                        |
|           | Light | Ink IC warning*1, Residual quantity 0 cartridge*2, No cartridge |

\*1 Ink IC warning: Errors related PIC such as NON-ORIGINAL INK, WRONG INK IC, Kind of INK, Color of INK, WRONG CARTRIDGE and Expiration:2MONTH.

\*2 Residual quantity 0 cartridge: A cartridge having no residual quantity after execution of the ink wear-up cleaning (a function to conduct cleaning with preferentially using a cartridge having NEAR END or INK END error). (4-color only)

Switching of supply cartridges occurs under the conditions shown below. (4-color only)

- “INK END” during the drawing
- “INK NEAR END” during the filling
- Ink IC warning
- When a cartridge is taken off.
- Ink wear up cleaning

If the filling is not 4-color, or if the filling is 4-color and switching is not possible within 1 supply system, the warning for the current supply cartridge is displayed. The followings are relations between warnings and operations.

| Local/Remote idle warning display<br>(state of supply system unit) |      | Guidance function warning display in detail<br>(state of cartridge unit) | Cleaning | Filling | Drawing |
|--|------|--|----------|---------|---------|
| NEAR END   |      | INK NEAR END   | ×        | ×       | *1      |
| INK END  | !CAR | INK END  | ×        | ×       | ×       |
|  |      | NO CARTRIDGE   |          |         |         |
|  |      | NON-ORIGINAL INK   |          |         |         |
|  |      | WRONG INK IC   |          |         |         |
|  |      | Kind of INK  |          |         |         |
|  |      | Color of INK   |          |         |         |
|  |      | WRONG CARTRIDGE  |          |         |         |
|  |      | Expiration:2MONTH  |          |         |         |
|  |      | Expiration:1MONTH  | ○        | ○       | *2      |
|  |      | Expiration   | ○        | ○       | ○       |

\*1 Transition to the LOCAL mode is executed after each completion of drawing.

\*2 In case of a month next to the ink expiration month, transition to the LOCAL mode is executed after each completion of drawing.

## Ink system error monitoring

### □ Operation at occurrence of an ink system error

Error check on ink system/cartridge is executed periodically (every 30 ms), and operation is restricted according to the error state.

Error contents/operation restrictions are shown in the table below.

#### <Ink system error>

| Priority | Ink system error                             | Executions at error |         |                  |                  | Error contents  |
|----------|--|---------------------|---------|------------------|------------------|---|
|          |  | CL/<br>Filling      | Drawing | Head<br>cleaning | Pump<br>cleaning |   |
| H        | Waste ink tank                               | ×                   | ×       | ×                | ×                | When there is a certain increase after waste ink near full counted by the firmware is displayed.  |
|          | Initial filling is not executed              | ×                   | ×       | ×                | ×                | Initial filling is not executed.  |
|          | Ink end error                                | ×                   | ×       | ○                | ○                | Errors occurred in both cartridges and drawing & suction operation can not be executed.   |
|          | Ink near end error                           | ×                   | ○       | ○                | ○                | <ul style="list-style-type: none"> <li>■Errors occurred in both cartridges and drawing &amp; suction operation can not be executed.</li> <li>■Returns to the local state at each completion of 1 file drawing.</li> </ul> |
|          | A waste ink tank is FULL soon now.           | ×                   | ○       | ×                | ×                | Waste ink tank is almost full. (Counted by the F/W)   |
|          | No cartridge                                 | ○                   | ○       | ○                | ○                | Cartridge is not installed.   |
|          | Ink IC *                                     | ○                   | ○       | ○                | ○                | <ul style="list-style-type: none"> <li>■An error related to the cartridge IC occurs.</li> <li>■Ink supply is disabled.</li> </ul>   |
|          | Residual quantity 0 cartridge (4-color only) | ○                   | ○       | ○                | ○                | <ul style="list-style-type: none"> <li>■Ink in the cartridge is used up.</li> <li>■Ink supply is disabled.</li> </ul>   |
|          | Cartridge ink end                            | ○                   | ○       | ○                | ○                | <ul style="list-style-type: none"> <li>■Quantity of ink in the cartridge reached to the predetermined amount.</li> <li>■Ink supply is disabled (CL can be used).</li> </ul>   |
|          | Cartridge near end                           | ○                   | ○       | ○                | ○                | <ul style="list-style-type: none"> <li>■The near end sensor detection board detects the state close to ink end.</li> <li>■Can be used for ink supplying at drawing or CL.</li> </ul>                                      |
|          | 1 months passed after ink expiration date    | ○                   | ○       | ○                | ○                | 1 months passed after ink expiration date.  |
|          | Announcement of nozzle cleaning execution    | ○                   | ○       | ○                | ○                | Urging execution of nozzle cleaning.  |
|          | Wiper replacement                            | ○                   | ○       | ○                | ○                | The number of usage times of a wiper exceeds the predetermined replacement number.  |
| L        | WashLiquidCart.NONE                          | ○                   | ○       | ○                | ×                | Washing solution cartridge is not installed.  |
|          | Washing solution cartridge                   | ○                   | ○       | ○                | ×                | Troubles on the ink washing solution cartridge.   |
|          | Wash Liquid END                              | ○                   | ○       | ○                | ×                | The washing solution cartridge is empty.  |
|          | Ink expiration of limitation period.         | ○                   | ○       | ○                | ○                | Ink expiration of limitation period.  |

\* Ink IC: NON-ORIGINAL INK, WRONG INK IC, Kind of INK, Color of INK, WRONG CARTRIDGE, Expiration:2MONTH

## Ink residual quantity control

Residual quantity of cartridge ink is calculated by subtracting ink consumption quantity obtained by calculation of number of ink shot times of drawing and flashing and ink suction amount by cleaning and filling from the ink residual quantity.

When ink residual quantity is updated, writing to the ink IC chip is executed.

A cartridge error is issued according to the residual quantity.

### □ Calculation of ink consumption quantity

The followings are calculation of ink consumption quantity at drawing, cleaning etc.

#### a) At drawing and flashing (ink discharging)

Ink consumption quantity at ink discharging is calculated with counting the number of ink shot times.



In JV33, as each dot size is counted at unit of each nozzle array, Small, Middle, Large, smaller error between actual measured value and calculated value can be expected.

#### b) At cleaning and filling (ink suction)

Ink consumption quantity at each operation is shown in the table below.

#### <Ink consumption quantity at ink suction (with 4-color)>

| Type                                |                | Ink consumption quantity in 1 supply path [cc] |
|-------------------------------------|----------------|--|
| Soft cleaning                       |                | 0.3  |
| Normal cleaning                     |                | 1.16   |
| High power cleaning                 |                | 5.8  |
| Maintenance filling                 |                | 13.0   |
| Initial filling<br>(No replacement) | Main suction   | 43.0   |
|                                     | Cobble filling | 4.1  |
| Initial filling<br>(At replacement) | Main suction   | 43.0   |
|                                     | Cobble filling | 4.1  |

### □ Updating of ink residual quantity

The ink residual quantity is updated at the following timings, and written in the ink IC chip.

#### <Ink residual quantity updating timing>

| Updating timing   | Conditions   |
|---|--|
| At pre-capping operation  | When ink is consumed by drawing or flashing.<br>Mainly at capping after completion of drawing.   |
| At completion of cleaning and filling operation   | Ink is consumed by cleaning and filling.<br>Cartridge residual quantity at using main suction is updated.  |
| When the following events occur at drawing and cleaning or filling.<br>■Cover OPEN<br>■Lever UP<br>■Media end | Ink consumption quantity until just before the events shown in the left is updated.  |
| When the following errors occur at drawing.<br>■Cartridge near end<br>■Cartridge ink end<br>■Cartridge error  | Updated just after occurrence of the error not waiting for writing at the capping pre-operation.<br>Update before replacing of cartridge during the drawing. |

**□ Errors related to ink residual quantity**

Errors related to ink residual quantity are shown in the table below.

**<Errors related to ink residual quantity>**

| Item   | Content  |
|--|--|
| Cartridge near end                           | Error arising timing:Residual quantity detection by the near end detection board.<br>Set value of each cartridge is as the followings.<br>220 cc cartridge: 20 cc<br>440 cc cartridge: 40 cc<br><br>Restrictions after arising of an error:<br>Initial filling is not allowed (drawing and cleaning is allowed). |
| Cartridge ink end                            | Error arising timing:Arising at consumption of predetermined quantity after the near end detection.<br><br>Restrictions after arising of an error:Drawing and initial filling are not allowed (cleaning is allowed).   |
| Residual quantity 0 cartridge (4-color only) | Error arising timing:Arising at residual quantity 0 after arising of ink end.<br>This error may arise only after cleaning by the ink wear-up cleaning.<br><br>Restrictions after arising of an error:<br>Drawing, initial filling and cleaning are not allowed.  |
| Cartridge error                              | Error arising timing:Arises when the ink end does not arise even if ink consumption quantity exceeds about double of ink cartridge capacity*.<br><br>Restrictions after arising of an error:<br>Drawing, initial filling and cleaning are not allowed.   |

\* Arises at 220cc cartridge: 400cc, 440cc cartridge: 800cc.

**Ink wear-up cleaning (4-color only)**

- The purpose of this cleaning is subduing ink consumption of a normal cartridge by using residual ink of a cartridge having “Cartridge near end” error or “Cartridge ink end” error by priority.
- When one cartridge is normal at starting of cleaning, residual ink side is sucked and after suction, switched to the normal cartridge to continue cleaning.
- When residual ink is used up (soft counter), “Residual quantity 0 cartridge” error is arisen to disable the cartridge.



Ink wear-up cleaning control is only effective in the normal cleaning, and it can not be executed at other cleanings or at initial filling.

## Ink Suction and Discharge Control

### Outline of control

- A roller pump (ink suction pump) is used for ink suction and ejection.
- The amount of ink discharged to the waste ink tank is counted by the firmware, and warnings are issued depending on the level. They are displayed in sequences involving ink suction and discharge, or locally. ( See [About the waste ink tank warning \(p. 2-6\)](#) )
- To prevent coagulation of ink in the ejection path tube between the cap and waste tank, there is a function for cleaning it automatically (pump tube cleaning). Cleaning is performed by drawing cleaning fluid from the cleaning fluid cartridge to the cap using the siphon principle. It is performed periodically when the power is turned on/off.

### Device configuration

The device configuration of ink suction and discharge is shown in a diagrammatic illustration below.





Fig.2-4 Diagrammed illustration of Ink Suction and Discharge Path

## Outline flow

### Points to note with 4-color filling

In initial filling, to eject air completely from the ink paths, suction is divided into 2 stages, (1) filling up to the coupler, and (2) filling up to the nozzle. Each uses the sub cartridge and control cartridge.



## Initial Filling

At device starting, when ink is not filled, initial filling is conducted. Operation sequence is as the following.

### <Initial filling operation sequence>

| No. | Item  | Content   |
|-----|---|---|
| 1   | Selection of model                          | A set value is selected among values shown below.<br><b>Set value: SOLVENT-INK spec, AQUEOUS-INK spec</b><br>■ Select only for initial filling at setup.  |
| 2   | Selection of ink type (Ink type)            | When SOLVENT-INK spec. is chosen, select the following setting values.<br><b>Set value: ES3 Sol, SS21 Sol</b><br>When AQUEOUS-INK spec. is chosen, select the following setting values.<br><b>Set value: PIG, Sb51</b>  |
| 3   | Selection of number of colors (Ink set)     | Except with Sb51, select the setting value below.<br><b>Set value: 4-Color (MMCCYYKK), 6-Color (MmCMcCKY), 6+W Color (MWCWYmKc) *Only when SS21 selected</b><br>With Sb51, select the setting value below.<br><b>Set value: 4-Color (MMBBYYKK), 6-Color (MmBMbBKY)</b>  |
| 4   | Preparing to fill the pre-fill up solution  | Discharging of the transportation liquid remaining in the ink paths.  |
| 5   | Filling of the pre-fill up solution         | Insert a pre-fill up solution cartridge in all slot to be sucked (All 8 cartridges)<br><br>■ Skipped with the AQUEOUS-INK spec.<br>■ If there is an occurrence of warning* in a pre-fill up solution cartridge, suction is not conducted.<br>■ Displayed when a waste ink tank warning occurs.  |
| 6   | Discharging of the pre-fill up solution     | Discharging of the pre-fill up solution.  |
| 7   | Filling of the ink                          | Inserting ink cartridges into all slots and ink filling is conducted.<br><br><4-color filling><br>1. Filling to the coupler<br>Within the same supply system, open the valves in the order of even columns -> odd columns, and fill the ink up to the coupler.<br>2. Fill up to the damper (head).<br><6-color filling><br>1. Open all of the valves and fill the ink up to the damper (head).<br><br>■ If a warning occurs in the ink cartridge, filling is not conducted.<br>■ Displayed when a waste ink tank warning occurs.<br>■ If a cartridge warning occurs during filling to the damper (head), filling is continued with replacing cartridges. (4-color only)<br>Filling is stopped when ink supply fails in one supply system. |
| 8   | Filling of the maintenance washing solution | Filling of exclusive washing solution for pump tube cleaning.<br>Insertion of the washing solution cartridge into a slot is confirmed and filling is conducted.<br>If a warning occurs in the washing solution cartridge, filling is not conducted.<br>Displayed when a waste ink tank warning occurs.  |

\* As an IC chip is not placed in a pre-fill up solution cartridge, it is recognized that IC chip read error means normal.

\* If performing a 6 (8)-color fill when installing the device, the couplers need to be change before the fill.

## 2-2. Functions

### 2-2-1. ADJUST Function

#ADJUST function comprises the following items executed at factory shipping or maintenance operation.

<Adjust functions>

| Item            | Content   | Reference page |
|-----------------|---|----------------|
| HEAD ADJUST     | Slant adjust, Dot position adjust.                                      | P.3-9          |
| HEAD WASH       | Cleaning of head, damper, tube  | P.2-21         |
| MANUALhead WASH | Manual cleaning of head, damper and tube at head replacement and so on. | P.2-22         |
| DEFAULT SET     | Initialization of the selection parameter                               | P.2-22         |
| CAPPING         | Capping, wiping position adjustment                                     | P.3-13         |
| HEAD ID         | Head ID inputting   | P.2-23         |
| MOTOR CURRENT   | Adjusting power current of X-axis motor, Y-axis motor                   | P.2-23         |
| SERIAL No       | Confirmation and input of device serial No.                             | P.2-24         |
| DEALER No       | Confirmation and input to device dealer No.                             | P.2-24         |
| EDGE ADJUST     | Adjusting margin in both sides of paper                                 | P.2-24         |
| MEDIA COMP.2    | Media basic feed amount compensation                                    | P.2-25         |
| POINTER OFFSET  | LED pointer position adjust.  | P.2-25         |
| EXCHANGE PARTS  | Display and input of parts, units replacement history                   | P.2-26         |

## HEAD WASH

Cleaning head, damper and tube.



As it is non-filling state after the completion of cleaning, the [Initial Filling \(p.2-19\)](#) or filling of corresponding head is required.

### <Head wash operation sequence>

| No. | Item  | Operation content   | Notice |
|-----|---|---|--------|
| 1   | Preparation                                 | Confirm the change of ink set.<br>During the initial filling after cleaning the head, select "Yes" if you changed the ink set.<br>(The ink set cannot be changed except when the device is first shipped, because the coupler needs to be changed)  |        |
| 2   | Discharging of ink                          | 1. Taking out cartridges (all slots). (Cartridge sensor monitoring)<br>2. Discharging ink (Ink suction motor driving)<br>Execute after the confirmation display when a waste ink tank warning occurs.   |        |
| 3   | Cleaning                                    | 1. Inserting washing solution cartridges (all slots). (Cartridge sensor monitoring* <sup>1</sup> )<br>2. Cleaning inside of tube (Opening cartridge valve, ink suction motor driving)<br>3. Head vibrating operation (Y-axis motor) is executed   |        |
| 4   | Discharging of washing solution             | 1. Taking out cleaning cartridges (all slots). (Cartridge sensor monitoring)<br>2. Discharging washing solution (ink suction pump motor driving)  |        |
| 5   | Repeating                                   | 3 ~ 4 are executed again.   |        |
| 6   | Wiper Cleaning                              | 1. Cap OFF<br>2. Wiper ON (after moving the carriage to the maintenance position)<br>Waiting for wiper cleaning end<br>([ENTER] pressing to start the following No.)  |        |
| 7   | Operation selection                         | Press one of a key below to select an operation.<br>[◀] : Transit to No. 10 (END)<br>[▶] : Transit to No. 8 (CONTINUE)<br>[▼] : Transit to No. 3 (Re-WASH)  |        |
| 8   | Filling of transportation liquid            | 1. Insert transportation liquid cartridge (all slots). (Cartridge sensor monitoring)<br>2. Fill head, damper and tube with transportation liquid<br>(Cartridge valve OPEN, Ink suction pump motor driving).   |        |
| 9   | Discharging of transportation liquid        | 1. Taking out of transportation liquid cartridges (all slots). (Cartridge sensor monitoring)<br>2. Discharge transportation liquid.(with leaving appropriate amount)<br>(Cartridge valve OPEN, Ink suction pump motor driving)  |        |
| 10  | Operation selection                         | Press one of a key below to select an operation.<br>[◀] : End of head cleaning(END)<br>[▶] : Transit to No. 11 (DISCHARGE) (Maintenance washing solution discharge)   |        |
| 11  | Maintenance washing solution discharge      | 1. Taking out the maintenance washing solution cartridge.<br>(maintenance washing solution slot)<br>2. Discharging maintenance washing solution.(pump motor driving)  |        |
| 12  | Operation selection                         | Press one of a key below to select an operation.<br>[◀] : End of head cleaning (END)<br>[▶] : Transit to No. 13 (FillUP) (Transportation liquid suction and discharge)  |        |
| 13  | Transportation liquid suction and discharge | 1. Inserting transportation liquid cartridge. (maintenance washing solution slot)<br>2. Transportation liquid suction (pump motor driving)<br>3. Taking out of transportation liquid cartridges. (maintenance washing solution slot)<br>4. Discharging transportation liquid (pump motor driving) |        |

\*1 As an IC chip is not placed in a washing solution cartridge, it is recognized that IC chip read error means normal

## MANUALhead WASH

At head cleaning with a syringe (after head replacement and so on), cap off to execute dry suction.

### <Manual head cleaning operation sequence>

| No. | Item    | Operation content   | Notice |
|-----|---------|---|--------|
| 1   | Suction | 1. Cap OFF<br>2. Dry suction (pressing <b>[ENTER]</b> to drive corresponding motor)<br>If a warning on waste ink tank arises, filling is not conducted.<br>(Waste tank sensor monitoring) |        |
| 2   | End     | Press <b>[ENTER]</b> to stop pump motor and return to 1.  |        |

## DEFAULT SET

Setting initial value to a selected parameter.

### <Default set>

| No. | Selection Item  | Operation content   | Notice  |
|-----|-----------------|---|---|
| 1   | SETUP PARAMETER | 1. Initialization of user operation setting value<br>2. Set user No. to 1<br>3. Initialization of language to be used<br>4. Initialization of User dot position compensation value<br>5. Set to maintenance close | Always selectable   |
| 2   | MAINTE. PARAM.  | Initializing the parameter in question  | Quasi-disclosure parameter (Selectable only at releasing) |
| 3   | CUSTOM. PARAM.  | Initializing the parameter in question  |   |
| 4   | RUNNING PARAM.  | Initializing the parameter in question  |   |
| 5   | EXCHANGE PARAM. | Initializing the parameter in question  |   |
| 6   | INKSYSTEMparam. | Initializing the parameter in question  |   |
| 7   | INKinfor.PARAM. | Initializing the parameter in question  |   |
| 8   | INKinfor.PARAM. | Initializing the parameter in question  |   |
| 9   | INKSEQUENCEpara | Initializing the parameter in question  |   |
| 10  | HEADunit PARAM. | <b>Unit selection: UNIT-1~4, ALL</b>  |   |
| 11  | SERVO PARAMETER | Initializing the parameter in question  |   |
| 12  | TEST PARAMETER  | Initializing the parameter in question  |   |
| 13  | CORRECT PARAM.  | Initializing the parameter in question  |   |
| 14  | ADJUST PARAM.   | Initializing the parameter in question  |   |

## HEAD ID

- Contents: Head ID input of JV33 is automatically executed by the system.  
The head memory PCB Assy is equipped on the head unit Assy (M007034, IH47V Head Unit Assy), the ID information is written in the head memory Assy.



Head ID is for compensating differences of discharge amount of ink among each head. A label on which a compensation value (ID) is written is attached on a head at shipping. Storing the ID in the Parameter of JV33 makes print quality constant.



**Manual input of the ID information is required in the following cases.**

- **In a case that the ID information is not stored in the head memory PCB Assy.**

“HEAD ID Un-Input” is displayed on the panel (at the power ON)

- **In a case that the head ID is not identical to the ID information in the PCB Assy. (when a PCB of another head is placed, for example).**

As the error is not displayed on the panel, taking care is required at replacing.

Manual ID input is recommended if there is a doubt on agreement between the ID of a head and the ID information in the memory PCB.

## MOTOR CURRENT

### □ STOP ADJUST

- Contents: Adjusting of power current of X-, Y-axis motor. Adjust value is stored in the system parameter.  
X-, Y-axis motor power current value and corresponding D/A value are displayed.

### ■ Key operation

[ENTER]: Transit to adjust mode

[◀], [▶]: Motor selection

[▲], [▼]: Change of D/A value

### □ X MOVING ADJUST/ Y MOVING ADJUST

- Contents: Adjust current value with driving X- or Y-axis motor.  
Current value of X- or Y-axis motor and corresponding D/A value are displayed.  
The operation sequence is as same as that of [#TEST] - [MOTOR TEST] - [ XY SERVO MOTOR].  
Adjust the D/A value with [▲] [▼] during the operation under designated conditions.  
The set value is stored at stopping with [END].

## SERIAL No

- Contents: Confirmation and setting of serial ID.  
8 characters of alphabet and numeral (0~9, A~Z) can be input.
- Key operation  
[▲], [▼]: Change value (cursor position)  
[◀], [▶]: Moving the cursor  
(When the cursor is in the left end or the right end, key input does not work)
- [ENTER]: Setting
- [END]: Input cancel



Cannot be changed if the serial number is set.

## DEALER No

- Contents: Confirmation and setting of dealer ID.  
8 characters of alphabet and numeral (0~9, A~Z) can be input.
- Key operation  
[▲], [▼]: Change value (cursor position)  
[◀], [▶]: Moving the cursor  
(When the cursor is in the left end or the right end, key input does not work)
- [ENTER]: Setting
- [END]: Input cancel

## EDGE ADJUST

- Contents: Adjust dead space size of both left and right ends of paper
- Key operation  
[◀]: Set adjust value of L, R to default (15.0 mm).  
[▶]: Execute media width detection to draw an adjust pattern.  
[▲], [▼]: Change adjust values
- [END]: Input cancel
- Adjust value: 0.0~35.0 mm (unit: 0.1 mm)  
Input actual measurement from media end to the pattern as an adjust value.  
If the unit is changed to inch, convert the value to inch to adjust.




Fig.2-5

Note: The set value is stored in the system parameter No.2 R GRIP, No.3 L GRIP as "current parameter value + (15 mm-input value)".

## MEDIA COMP.2

■ Contents: Basic feeding amount of media is compensated.

■ Key operation

[ENTER]: Drawing an adjusting pattern

[▶]: Input compensation value without drawing the adjusting pattern

[END]: Complete drawing and input compensation value.

■ Compensation value: -500 ~ 500

In actual feeding amount compensation, compensation for each media set in the SET UP function is added to this compensation value.




Fig.2-6

## POINTER OFFSET

■ Contents: Plots an adjustment pattern, and adjusts the position of the LED pointer and plotting origin (nozzle A array).

■ Key operation

[ENTER]: Drawing start

After completion of plotting

[▲], [▼], [◀], [▶]: LED pointer positioning

Focuses the LED pointer on the following pattern position (intersection point of lines).

[ENTER]: Setting

[END]: Input cancel




Fig.2-7

## EXCHANGE PARTS

Displaying of replacement date history of parts/unit, or registering of replacement date.

### □ REGISTRATION

Parts replacement history is registered.

Select a part to be registered and input date and part number. Effective part numbers are as the followings.

| Type   | Part number                      |
|--------|----------------------------------|
| Pump   | Number is not input              |
| Cap    | Number is not input              |
| Damper | A~H registration (nozzle number) |



**JV33 determines timing of replacement of above parts.**

**When a part in question is replaced, never forget to register the replacement date.**

### □ HISTORY


The latest history is displayed at starting. (Switching is allowed with [▲], [▼])

As for a head, as it is recorded automatically at first starting after replacement, registration is not required. (Confirmation of history is allowed)

Layout of each part is shown in the following drawing.

#### Damper

Designate with nozzle row (A~H)



~Top view of head~

Fig.2-8

## 2-2-2. TEST Function

The test function comprises the following items executed in shipping, and the maintenance operation.

### <Test function item>

| Item            | Content  | Reference page |
|-----------------|--|----------------|
| CHECK PATTERN   | Drawing of various type of check patterns.<br>100%, 50%, 25%, 12.5%, 6.25% (Density pattern)<br>NOZZLE CHECK, COLOR CHART, DROP.POS CHK      | P.2-28         |
| ALL PATTERN     | Drawing of adjusting pattern.  | P.2-29         |
| MOTOR TEST      | Operation test of various motors.<br>X SERVO MOTOR, Y SERVO MOTOR, XY SERVO MOTOR,<br>WIPER MOTOR, PUMP MOTOR, TAKE-UP MOTOR                 | P.2-29         |
| HEATER TEST     | Test of media heater<br>TEMPERATURE, SSR   | P.2-31         |
| WARMING TEST    | Test of head warming heater  | P.2-32         |
| ACTION TEST     | Operation Test of various fan motor, cutter, valve<br>VACUUM FAN, BUILTInDEOD.FAN, Y-CUTTER, HDC 1&2 FAN,<br>DEOD.FAN & DRY FAN, LED pointer | P.2-32         |
| SENSOR TEST     | Test of various sensors<br>SET LEVER, R.PAPER, Y-ORIGIN, WIPER, FRONT COVER, HEAD<br>HEIGHT  | P.2-33         |
| OPTION          | Check the connection status of take-up, dryer, and the exhaust fan.  | P.2-33         |
| KEYBOARD LED    | Heater (CONSTANT, HEAT), and ACTIVE LED operation test.  | P.2-33         |
| PAPER SENSOR    | Test of media width sensor   | P.2-34         |
| KEYBOARD TEST   | Test of panel SW   | P.2-34         |
| LCD TEST        | Test of LCD  | P.2-34         |
| TIMER CHECK     | Confirmation and setting of device time  | P.2-34         |
| MEMORY CHECK    | Check of various memory<br>MAIN.SDRAM, MAIN.F-ROM, HEAD.EEPROM   | P.2-35         |
| SKEW CHECK      | Media skew check   | P.2-36         |
| TEMPERATURE.CHK | Display of temperature around head<br>HEAD TEMP., NOZZLE TEMP., HEAT SINK TEMP., SLIDER TEMP.  | P.2-36         |
| LINEAR ENCODER  | Test of linear encoder.  | P.2-37         |
| INK CARTRIDGE   | Test around cartridge.<br>PACK&END SENSOR, CARTRIDGE VALVE, CARTRIDGE LED, INK-IC<br>CHECK   | P.2-37         |
| WASH CARTRIDGE  | Test around cleaning cartridge.<br>PACK&END SENSOR, CARTRIDGE VALVE, IC CHECK  | P.2-37         |

## CHECK PATTERN

The following 4 types of drawing are allowed in check pattern. Procedure of pattern drawing is shown in the table below

- Density pattern
- NOZZLE CHECK
- COLOR CHART
- DROP.POS CHK

### <Check pattern drawing procedure>

| No.        | Item                                  | Content   |            |                 |                 |          |             |              |          |               |               |           |              |               |          |              |              |          |             |              |           |              |               |           |              |               |            |           |            |
|------------|---------------------------------------|---|------------|-----------------|-----------------|----------|-------------|--------------|----------|---------------|---------------|-----------|--------------|---------------|----------|--------------|--------------|----------|-------------|--------------|-----------|--------------|---------------|-----------|--------------|---------------|------------|-----------|------------|
| 1          | Selection of density*2                | ALL, 100%, 50%, 25%, 12.5%, 6.25%   |            |                 |                 |          |             |              |          |               |               |           |              |               |          |              |              |          |             |              |           |              |               |           |              |               |            |           |            |
| 2          | Selection of resolution               | 540x 720, 540x 900, 540x1080, 720x 540<br>720x 720, 720x1080, 720x1440, 1440x1440   |            |                 |                 |          |             |              |          |               |               |           |              |               |          |              |              |          |             |              |           |              |               |           |              |               |            |           |            |
| 3          | Selection of can direction            | Bi-D, Uni-D   |            |                 |                 |          |             |              |          |               |               |           |              |               |          |              |              |          |             |              |           |              |               |           |              |               |            |           |            |
| 4          | Selection of No. of passes            | <table border="1"> <thead> <tr> <th>Resolution</th> <th>Passes(4 color)</th> <th>Passes(6 color)</th> </tr> </thead> <tbody> <tr> <td>540x720:</td> <td>2, 4, 8, 16</td> <td>4, 8, 16, 32</td> </tr> <tr> <td>540x900:</td> <td>5, 10, 20, 40</td> <td>5, 10, 20, 40</td> </tr> <tr> <td>540x1080:</td> <td>3, 6, 12, 24</td> <td>6, 12, 24, 48</td> </tr> <tr> <td>720x540:</td> <td>3, 6, 12, 24</td> <td>3, 6, 12, 24</td> </tr> <tr> <td>720x720:</td> <td>2, 4, 8, 16</td> <td>4, 8, 16, 32</td> </tr> <tr> <td>720x1080:</td> <td>3, 6, 12, 24</td> <td>6, 12, 24, 48</td> </tr> <tr> <td>720x1440:</td> <td>4, 8, 16, 32</td> <td>8, 16, 32, 64</td> </tr> <tr> <td>1440x1440:</td> <td>8, 16, 32</td> <td>16, 32, 64</td> </tr> </tbody> </table> | Resolution | Passes(4 color) | Passes(6 color) | 540x720: | 2, 4, 8, 16 | 4, 8, 16, 32 | 540x900: | 5, 10, 20, 40 | 5, 10, 20, 40 | 540x1080: | 3, 6, 12, 24 | 6, 12, 24, 48 | 720x540: | 3, 6, 12, 24 | 3, 6, 12, 24 | 720x720: | 2, 4, 8, 16 | 4, 8, 16, 32 | 720x1080: | 3, 6, 12, 24 | 6, 12, 24, 48 | 720x1440: | 4, 8, 16, 32 | 8, 16, 32, 64 | 1440x1440: | 8, 16, 32 | 16, 32, 64 |
| Resolution | Passes(4 color)                       | Passes(6 color)   |            |                 |                 |          |             |              |          |               |               |           |              |               |          |              |              |          |             |              |           |              |               |           |              |               |            |           |            |
| 540x720:   | 2, 4, 8, 16                           | 4, 8, 16, 32  |            |                 |                 |          |             |              |          |               |               |           |              |               |          |              |              |          |             |              |           |              |               |           |              |               |            |           |            |
| 540x900:   | 5, 10, 20, 40                         | 5, 10, 20, 40   |            |                 |                 |          |             |              |          |               |               |           |              |               |          |              |              |          |             |              |           |              |               |           |              |               |            |           |            |
| 540x1080:  | 3, 6, 12, 24                          | 6, 12, 24, 48   |            |                 |                 |          |             |              |          |               |               |           |              |               |          |              |              |          |             |              |           |              |               |           |              |               |            |           |            |
| 720x540:   | 3, 6, 12, 24                          | 3, 6, 12, 24  |            |                 |                 |          |             |              |          |               |               |           |              |               |          |              |              |          |             |              |           |              |               |           |              |               |            |           |            |
| 720x720:   | 2, 4, 8, 16                           | 4, 8, 16, 32  |            |                 |                 |          |             |              |          |               |               |           |              |               |          |              |              |          |             |              |           |              |               |           |              |               |            |           |            |
| 720x1080:  | 3, 6, 12, 24                          | 6, 12, 24, 48   |            |                 |                 |          |             |              |          |               |               |           |              |               |          |              |              |          |             |              |           |              |               |           |              |               |            |           |            |
| 720x1440:  | 4, 8, 16, 32                          | 8, 16, 32, 64   |            |                 |                 |          |             |              |          |               |               |           |              |               |          |              |              |          |             |              |           |              |               |           |              |               |            |           |            |
| 1440x1440: | 8, 16, 32                             | 16, 32, 64  |            |                 |                 |          |             |              |          |               |               |           |              |               |          |              |              |          |             |              |           |              |               |           |              |               |            |           |            |
| 5          | Selection of drawing size             | X size: 10 mm ~ paper length (unit: 10 mm) *Roll paper: 500000 mm<br>Y size: 10 mm ~ paper width (unit: 10 mm)  |            |                 |                 |          |             |              |          |               |               |           |              |               |          |              |              |          |             |              |           |              |               |           |              |               |            |           |            |
| 6          | Selection of drawing color*1          | 6 colors: M, C, Y, K, c, m (M, B, Y, K, b, m with Sublimation5 ink)<br>4 colors: M, C, Y, K (M, B, Y, K, with Sublimation5 ink)   |            |                 |                 |          |             |              |          |               |               |           |              |               |          |              |              |          |             |              |           |              |               |           |              |               |            |           |            |
| 7          | Drawing start (waiting for key input) | <p><b>[ENTER]</b>: Drawing start</p> <p><b>[TEST]</b>: Execution of test drawing</p> <p><b>[(JOG)]</b>: JOG operation mode<br/>Press <b>[ENTER]</b> to start drawing with setting the current position as the original position.</p> <p><b>[REMOTE]</b>: Setting of high speed scan ON/OFF</p> <p><b>[END]</b>: END of drawing</p>  |            |                 |                 |          |             |              |          |               |               |           |              |               |          |              |              |          |             |              |           |              |               |           |              |               |            |           |            |

\*1 COLOR CHART, DROP.POS CHK do not have these items.

\*2 Density pattern, NOZZLE CHECK and DROP.POS CHK do not have these items.

### <Example of DROP.POS CHK pattern printing>




Fig.2-9

## ALL PATTERN

The following check patterns are drawn in the block.

| Check pattern                                   | Reference page |
|---|----------------|
| Slant adjusting pattern                         | P.3-10         |
| Y-impact position adjusting pattern (FINE Y Bi) | P.3-11         |

## MOTOR TEST

The following 6 motors are tested.

<Motor>

| Motor name     | Reference page |
|----------------|----------------|
| X SERVO MOTOR  | P.2-29         |
| Y SERVO MOTOR  | P.2-29         |
| XY SERVO MOTOR | P.2-30         |
| WIPER MOTOR    | P.2-30         |
| PUMP MOTOR     | P.2-31         |
| TAKE-UP MOTOR  | P.2-31         |

### □ X SERVO MOTOR

Operation of X-servo motor is executed.

<X (Y)-servo motor test sequence>

| No. | Item                      | Content  | Notice                                     |
|-----|---------------------------|--|--|
| 1   | Speed designation         | [▲], [▼]: Speed selection set value<br>Set value: 1 ~ 150 mm/s (unit: 1 mm/s) (at X-axis motor test)<br>Set value: 1 ~ 1500 mm/s (unit: 1 mm/s) (at Y-axis motor test) | [◀], [▶]: Selection of item 2~4            |
| 2   | Acceleration designation  | [▲], [▼]: Acceleration selection<br>Set value: 0.01 ~ 0.50G (unit: 0.01 G) (at X-axis motor test)<br>Set value: 0.05 ~ 2.00G (unit: 0.05 G) (at Y-axis motor test)     |  |
| 3   | Moving amount designation | [▲], [▼]: Moving amount selection<br>Set value: 1 mm ~ paper length (width) (unit: 1 mm)<br>When media is not detected X-axis motor: 1 mm~500000 mm                    |  |
| 4   | Cap OFF                   |  | Only Y-moter<br>Only after media detection |
| 5   | Move                      | [ENTER]: Reciprocating motion in the X (Y) direction with designated conditions is repeated.   |  |
| 6   | End                       | [END]: Return to the motion starting position and execute capping to end.  |  |

Note: During the test, heater temperature control is allowed (When HEATER key is effective).

### □ Y SERVO MOTOR

Operation of Y-servo motor is executed.

Operation sequence is as same as that of X-axis motor test. (See the operation sequence above.)

**□ XY SERVO MOTOR**

Operation test of XY-servo motor is executed.

<XY-servo motor test sequence>

| No. | Item                        | Content   | Notice   |
|-----|-----------------------------|---|--|
| 1   | X speed designation         | [▲], [▼]: Speed selection<br>Set value: 1 ~ 150 mm/s (unit: 1 mm/s)   | [◀], [▶]: Selection of item 2~4<br><br>[ENTER]: Transit to setting in the Y direction (5~)   |
| 2   | X acceleration designation  | [▲], [▼]: Acceleration selection<br>Set value: 0.01 ~ 0.50 G (unit: 0.01 G)   |  |
| 3   | X moving amount designation | [▲], [▼]: Moving amount selection<br>Set value: 1 mm ~ Paper length (unit: 1 mm)<br>When media is not detected: 1 mm ~ 500000 mm<br>press [ENTER] to start Y-axis motor setting   |  |
| 4   | Y speed designation         | [▲], [▼]: Speed selection<br>Set value: 1 ~ 1500 mm/s (unit: 1 mm/s)  | [◀], [▶]: Selection of item 5~7<br><br>[ENTER]: Transit to the following step<br><br>[END]: Transit to setting in the X direction (2~) |
| 5   | Y acceleration designation  | [▲], [▼]: Acceleration selection<br>Set value: 0.05 ~ 2.00 G (unit: 0.05 G)   |  |
| 6   | Y moving amount designation | [▲], [▼]: Moving amount selection<br>Set value: 1 mm ~ Paper width (unit: 1 mm)<br>When media is not detected: 1 mm ~ Mechanical limit size   |  |
| 7   | Cap OFF                     |   | Only after media detection   |
| 8   | Moving                      | [ENTER]: The following motion is repeated with the designated conditions.<br>(During the motion, No. of Y reciprocation is displayed.)<br>a) Y designated distance moving<br>b) X designated distance moving, Move to Y starting position |  |
| 9   | End                         | [END]: Return to the motion starting position and execute capping to end.   |  |

Note: During the test, heater temperature control is allowed (When HEATER key is effective).

**□ WIPER MOTOR**

Operation test of wiper motor is executed.

<Wiper motor test sequence>

| No. | Item                      | Content  | Notice                          |
|-----|---------------------------|--|---------------------------------|
| 1   | Driving speed designation | [▲], [▼]: Selection of driving speed of the motor<br>Set value: 100 ~ 4000 pps (unit: 100 pps)                           | [◀], [▶]: Selection of item 1~3 |
| 2   | WAIT designation          | [▲], [▼]: Designating operation interval<br>Set value: 0~60 sec (unit: 1 sec)  |                                 |
| 3   | Count designation         | [▲], [▼]: Designating No. of operation times<br>Set value: CONTINUE, 1~1000 count (unit: 1 count)                        |                                 |
| 4   | Test start                | [ENTER]: Driving the motor with designated conditions<br>When CONTINUE is selected in count setting, finished with [END] |                                 |
| 5   | Test end                  | Wiper is returned to the original position.  |                                 |

## □ PUMP MOTOR

Operation test of pump motor is executed.

### <Pump motor test sequence>

| No. | Item                           | Content   | Notice   |
|-----|--------------------------------|---|--|
| 1   | Pump selection                 | [◀], [▶]: Pump selection (Move cursor)<br>[▲], [▼]: Operation selection   | [◀], [▶]: Selection of item 1~3  |
| 2   | Rotation direction selection   | [▲], [▼]: Pump rotation direction selection<br>Set value: FORWARD, REVERSE  |  |
| 3   | Driving speed designation      | [▲], [▼]: Select driving speed<br>Set value: 100~4000 pps (unit: 100 pps)   |  |
| 4   | Carriage/Motor state selection | <b>[FUNCTION]</b> : Carriage/motor state at test selection menu is displayed<br><Carriage> IN: Execution at cap position / OUT: execution after carriage out<br><Motor> ON: Execution with Y-axis motor ON / OFF: execution with Y-axis motor OFF |  |
| 5   | Test start                     | <b>[ENTER]</b> : Cap OFF, carriage is moved to maintenance position. Pump motor is driven with designated conditions.<br><b>[END]</b> : End   | During operation, open and close the cartridge valve with the <b>[FUNCTION]</b> key. |
| 6   | Test end                       | Test end  |  |

Note: Be careful when executing (FORWARD) while the cap motor is on because this will become a vacuum suction..

## □ TAKE-UP MOTOR

Operation test of take-up motor is executed.

### <Take-up motor test sequence>

| No. | Item       | Content  | Notice |
|-----|------------|--|--------|
| 1   | Test start | <b>[ENTER]</b> : Take-up motor is driven<br>(Switching of winding direction, or operation stop is allowed with SW of winding device) |        |
| 2   | Test end   | <b>[END]</b> : End   |        |

## HEATER TEST

Various tests of the media heater are executed.

### <Heater test>

| Item        | Content  |
|-------------|--|
| TEMPERATURE | Control test of heater set temperature is executed.<br>Temperature settings of Pre, Print, After Heater are executed to control heater.<br>Set value (Celsius): OFF, 20 ~ 50 °C (unit: 1 °C)<br>Set value (Fahrenheit): OFF, 68 ~ 122 °F (as converted from celsius, unit is not 1 °F) |
| SSR         | ON/OFF of heater is executed.<br>Heater is turned to ON/OFF according to ON/OFF designation of pre, print, after heater.<br>(Heater temperature control is not conducted)  |

Note1: Temperature is displayed with a unit selected in the UNIT SETUP of the MACHINE SETUP function.

Note2: A/D conversion value is also displayed.

## WARMING TEST

---

Control test of the head warming heater ON/OFF is executed.

### <Warming test>

| Item        | Content  |
|-------------|--|
| TEMPERATURE | Controlling the heater temperature with the temperature setting of the warming heater (each head).<br>Temperature and ON/OFF of each heater are displayed during the temperature control.<br>Set value (Celsius): OFF, 20 ~ 45 °C (unit: 1 °C)<br>Set value (Fahrenheit): OFF, 68 ~ 113 °F (as converted from celsius, unit is not 1 °F) |

Note1: Temperature is displayed with a unit selected in the UNIT SETUP of the MACHINE SETUP function.

## ACTION TEST

---

Operation of the following parts/units is tested.

### <Action test>

| Item               | Content  |
|--------------------|--|
| VACUUM FAN         | Contents: Operation test of vacuum fan motor<br>Set value: L.L, LOW, MID, HIGH, OFF  |
| Y-CUTTER           | Contents: Operation test of media cutter.<br>Set value: UP, DOWN<br>Operation interval of Y-cutter is set with <b>[FUNCTION]</b><br>[▲], [▼]: Operation interval setting<br>Set value: 0 ~ 7200 sec (unit: 1 sec)<br><b>[ENTER]</b> : UP, Down is repeated with set interval<br>Number count is displayed during the test. |
| HDC FAN 1&2        | Contents: Operation test of HDC fan<br>Set value: ON, OFF  |
| DEOD.FAN & DRY FAN | Contents: Optional operation test of dryer/exhaust fan motor.<br>Set value: ON, OFF  |
| LED POINTER        | Contents: Operation test of LED pointer.<br>Set value: ON, OFF   |

## SENSOR TEST

---

Various sensors are tested.

Before starting the test, turn the servo motor and stepping motor to OFF, after finishing the test, initial operation of original position detection is executed.

### <Sensor test>

| Sensor      | Content   | LCD display |
|-------------|---|-------------|
| SET LEVER   | State display of clamp lever sensor                   | ON/OFF      |
| R.PAPER     | State display of rear paper sensor                    | ON/OFF      |
| Y-ORIGIN    | State display of Y-original position sensor.          | ON/OFF      |
| WIPER       | State display of wiper sensor                         | ON/OFF      |
| FRONT COVER | State display of cover sensor (front, maintenance LR) | ON/OFF      |
| HEAD HEIGHT | Displaying the state of head height sensor            | ON/OFF      |

## OPTION

---

Connection check of all optional devices.

TAKE-UP: winding device

EXHAUST: exhaust fan

DRYER: dry fan

“OFF” when not connected, and “ON” when the respective device is connected in the correct location.



**Since the shape of all the connectors is the same, they can be connected anywhere. However, if they are connected in the wrong place, the devices will not work.**

## KEYBOARD LED

---

ON/OFF test of the keyboard LEDs.

Heater LEDs: Pre, Print, and After heat LEDs

ACTIVE LED

Controls the LEDs above according to the ON/OFF designation.

## PAPER SENSOR

---

Paper width sensor is tested.

Cap OFF (station moved to the lowest position), reading of paper width sensor is displayed.

\*\*\* (@@@, \$\$\$) @@@ : Sensor reading at SLOP-ON  
\$\$\$ : Sensor reading at SLOP-OFF  
\*\*\*: Difference between @@@ and \$\$\$

Sensor reading is updated periodically (every 150 msec).

[◀], [▶]:Head move

[▲], [▼]:Alternately move to paper existing position and non-existing position in the right end of media.

[END]:After cap ON, paper sensor ends

## KEYBOARD TEST

---

Panel SW is tested.

When a panel SW is pressed, name of the SW is displayed on LCD.

When no key is pressed, "NONE" is displayed.

When [END] is pressed, "END TEST" is displayed and the keyboard test ends.

## LCD TEST

---

Characters are displayed on LCD.

When the LCD Test is started, scrolling of character code of 0x21 ~ 0xFF in one line is repeated. Press [END] to stop the test.

## TIMER CHECK

---

Confirmation and setting of date and time of the device.

Inputting of past date is only allowed present day -8H. Other date is an error.

\*Machine setting →Same as the time setting

Set value:20YY.MM.DD HH:MM:00

YY : 00~50

MM : 01~12

DD : 01~31

HH : 00~23

MM : 00~59

Returning to the last setting is allowed by pressing [FUNCTION] in the Date, Time Display State (not the Entering State). (However, the time elapsed after the setting change is added.)

## MEMORY CHECK

Variety of memory of the device is checked.

The memory check requires the following time. (1 count)

MAIN.SDRAM : Approx. 12 min.

MAIN.F-ROM : 1 sec.

HEAD.EEPROM : Approx. 22 sec.

### <Memory check>

| Item                      | Content  |
|---------------------------|--|
| MAIN.SDRAM* <sup>1</sup>  | <p>Read/Write check of SDRAM</p> <p>Select insert/not insert of wait time (30sec) between data write and read.<br/>In the checking the following process is counted as 1 and repeat until <b>[END]</b> is input.</p> <ol style="list-style-type: none"> <li>0000000h is written into from address 0 to all area of SDRAM.</li> <li>Read vacant data from address 0 to all area of SDRAM sequentially to confirm the reading meet the writing data.</li> <li>FFFFFFFFh is written into from address 0 to all area of SDRAM.</li> <li>Read vacant data from address 0 to all area of SDRAM sequentially to confirm the reading meet the writing data.</li> <li>Write increment data of 00010203h, 04050607h, ... FCFDFE00h into from address 0 to all area of SDRAM.</li> <li>Read vacant data from address 0 to all area of SDRAM sequentially to confirm the reading meet the writing data.</li> </ol> |
| MAIN.F-ROM                | <p>Hash check of F-ROM.</p> <p>In the checking, it is confirmed that long ward size SUM value from address 0 of F-ROM is 0001f000H*<sup>2</sup>, that is counted as 1, the process is repeated until <b>[END]</b> is input.</p> <p>If the SUM value is not 0001f000H, the check process is aborted and an error is displayed.</p>  |
| HEAD.EEPROM* <sup>1</sup> | <p>Read/Write check of HEAD.EEPROM</p> <p>Select a head unit to be checked.<br/>Before starting the checking, save contents of EEPROM in S-RAM (head unit parameter area).<br/>In the checking the following process is counted as 1 and repeat until <b>[END]</b> is input.</p> <ol style="list-style-type: none"> <li>Write 00h in from address 0 of HEAD.EEPROM, confirm that read value is 00h</li> <li>Write FFh in from address 0 of HEAD.EEPROM, confirm that read value is FFh.</li> <li>Write increment data of 00h, 01h, 02h, ..., FDh, FEh, 00h, ...in from address 0 of HEAD.EEPROM, confirm that read value agrees.</li> </ol>  |

Note: No. of counts is displayed during the check.

\*1 When data does not agree, the check process is aborted, and memory address, write/read data at occurrence of the error are displayed.

\*2 As sector 1~10 used by parameter are passed, SUM value is not 0.

## SKEW CHECK

Skewing of media is checked.

When media is not detected, an operation error (ERROR30) is displayed.

Feed distance is designated to execute feeding.

Feed distance: 1~500 m (unit: 1 m)

During the feeding, remaining of feed distance is displayed with unit of 10 mm.

[END]: Feeding abort, [ENTER]: Start feeding again.

### □ Cut jig function

After the Skew check starts, (feed distance is not designated) the following operation starts the cut jig function.

[REMOTE] →[FUNCTION]

The cut jig function repeats media cut →feed with designating feed distance and number of cut times.

Number of cut times is displayed in count down during cut.

Feed distance: 10~10000 mm (unit: 10 mm Default: 500 mm)

Number of cut times: 1~1000 count (unit: 1 count Default: 25 count)

## TEMPERATURE.CHK

### <Temperature check test>

| Item            | Content  |
|-----------------|--|
| HEAD TEMP.      | Environment temperature of head is displayed (A/D value is also displayed).<br>Displaying of head temperature uses a unit selected in the UNIT SETUP of the MACHINE SETUP.         |
| NOZZLE TEMP.    | Nozzle temperature error check is executed.<br>At Normal: OK is displayed<br>At error: NG is displayed   |
| HEAT SINK TEMP. | Temperature of HDC board heatsink is displayed (A/D value is also displayed).<br>Displaying of heatsink temperature uses a unit selected in the "UNIT SETUP" of the MACHINE SETUP. |
| SLIDER TEMP.    | Temperature read from the thermistor on the slider PCB is displayed (A/D value is also displayed).   |

## LINEAR ENCODER

### <Encoder test>

| Item           | Content   |
|----------------|---|
| LINEAR ENCODER | <p>Linear scale, Linear sensor are tested.</p> <p>Moving a carriage with designated distance (3 reciprocations), difference of linear encoder value and Y-axis motor encoder value is displayed. If an error arises during the operation, the test is aborted.</p> <p>Moving distance: 100 mm ~ Maximum actual operation limit (unit: 100 mm)</p> <p>LCD display is as the following. (M*: Y-axis motor encoder, E*: linear encoder)</p> <ul style="list-style-type: none"> <li>• Moving distance: M=****.* E=****.* (unit: 0.1 mm)</li> <li>• Difference of encoder values before moving and after moving:<br/>Mc=****.* Ec=****.* (unit: 0.1 mm)</li> <li>• Encoder values before moving: Ms=***** Es=*****</li> <li>• Encoder values after moving: Mm=***** Em=*****</li> <li>• Encoder values after moving with designated distance:<br/>Mr=***** Er=*****</li> </ul> |

## INK CARTRIDGE

### <Ink cartridge test>

| Item            | Content  |
|-----------------|--|
| PACK&END SENSOR | <p>Displaying state of cartridge exist/non-exist sensor and end sensor.</p> <p>A slot number on which an error (No cartridge, Ink near end) is found is displayed.</p> <p>[-2-----] (Example of LCD display)</p> |
| CARTRIDGE VALVE | Checking open/close of cartridge valve   |
| CARTRIDGE LED   | Light/Off of cartridge LED is tested.  |
| INK-IC CHECK    | <p>Ink cartridge IC is checked.</p> <p>In the check, IC chip data is read, number of occurrence of errors at each cartridge is displayed.</p>  |

## WASH CARTRIDGE

### <Wash cartridge test>

| Item            | Content  |
|-----------------|--|
| PACK&END SENSOR | <p>Displaying state of cartridge exist/non-exist sensor and end sensor</p> <p>[ON, OFF] (Example of LCD display)</p>                           |
| CARTRIDGE VALVE | Open/Close of cartridge valve is checked.  |
| IC CHECK        | <p>Maintenance washing solution IC is checked.</p> <p>IC chip data is read to be checked and the number of error occurrences is displayed.</p> |

### 2-2-3. Special Key Function

A function executed with pressing certain key SW at starting the device, the function starts the device with the following modes.

<Special key mode>

| Mode                        | Starting operation  | State after reset      |
|-----------------------------|---|------------------------|
| F/W update mode             | [REMOTE] + Main power ON  | Keeping previous state |
| Parameter Up/Down load mode | [▲] + [▼] + Main power ON                                       | Keeping previous state |
| Maintenance open mode       | [REMOTE] + [FUNCTION] + Main power ON                           | User mode              |
| System parameter input mode | [◀] + [▶] + Main power ON<br>or [ENTER] + [END] + Main power ON | User mode              |

#### F/W update mode

Receiving ROM data from the host computer through USB2.0 I/F to update device F/W, or rewriting of ink information.

Starting method: Starting with pressing [REMOTE]



Only enabled when starting up with the main power supply (side of the equipment).

In JV33, the following updates are allowed.

- Main board F/W

#### Parameter Up/Down load mode

Parameter data, log data are Up/Down loaded via USB I/F with the Host computer.

Starting method: Starting with pressing [▲] + [▼].

Upload, Download is instructed by the host PC (F/W update tool) with an exclusive maintenance command.



Fig.2-10

#### Maintenance Open Mode

Starts the device in maintenance open state

Starting method: Start with pressing [REMOTE] + [FUNCTION].

## System Parameter Input Mode

Starts the device in system parameter input state of #PARAMETER function.  
This function is for initializing parameters when starting of device is disabled to start because of parameter hash error and so on.

Starting method: Starts with pressing [ ◀ ] + [ ▶ ] (Or starts with pressing [ENTER] + [END]).

### 2-2-4. PARAMETER Function

PARAMETER function is a function to confirm and set parameters in the device.

<Parameter function item>

| No. | Item            | Stored place                           | Notice |
|-----|-----------------|--|--------|
| 1   | SYSTEM PARAM.   | F-ROM sector 2                         |        |
| 2   | MAINTE PARAM.   | F-ROM sector 2                         |        |
| 3   | CUSTOM PARAM.   | F-ROM sector 2                         |        |
| 4   | RUNNING PARAM.  | F-ROM sector 1 /Backup SRAM            |        |
| 5   | EXCHANGE PARAM. | F-ROM sector 2                         |        |
| 6   | INKSYSTEM PARAM | F-ROM sector 2                         |        |
| 7   | INKinfor.PARAM. | F-ROM sector 2,8,9                     |        |
| 8   | INKSEQUENCEpara | F-ROM sector 2,8,9                     |        |
| 9   | INKTYPE PARAM.  | F-ROM sector 2,8,9                     |        |
| 10  | HEADunit PARAM. | F-ROM sector 1 /Backup SRAMHEAD.EEPROM |        |
| 11  | SERVO PARAMETER | F-ROM sector 2                         |        |
| 12  | TEST PARAMETER  | F-ROM sector 2                         |        |
| 13  | CORRECT PARAM.  | F-ROM sector 2                         |        |
| 14  | ADJUST PARAM.   | F-ROM sector 2                         |        |

Note: While accessing F-ROM and HEAD.EEPROM, display [F-ROM WRITING] and light up BUSY LED (red).


No.1~6: Default selection is allowed

No.7~14: Selection is allowed only at the maintenance open


# 2-3. Operation Flow

## 2-3-1. Outline

The followings are items to be operational at the maintenance open. As for the operation flow at the maintenance close, see the operation manual.





## 2-3-2. SETUP






### 2-3-3. MAINTENANCE







□ DISCHARGE&WASH




### 2-3-4. MACHINE SET




## 2-3-5. COMMON SETUP




## 2-3-6. INFORMATION




## 2-3-7. ADJUST






□ HEAD WASH




### 2-3-8. TEST











## 2-3-9. PARAMETER







# CHAPTER 3 Overhaul / Adjustment

---

---

## *Contents*

|  |      |
|--|------|
| 3-1. Outline .....                       | 3-2  |
| 3-2. Overhaul of Covers .....            | 3-4  |
| 3-3. Overhaul of Ink-related Parts ..... | 3-6  |
| 3-4. Overhaul of PCBs .....              | 3-18 |
| 3-5. Overhaul of Sensors .....           | 3-26 |
| 3-6. Overhaul of Driving Parts .....     | 3-27 |
| 3-7. Overhaul of Other Parts .....       | 3-44 |



## 3-1. Outline

This chapter describes disassembly and reassembly of JV33-130/160. The description given here is chiefly of disassembly procedures. As a rule, reverse the disassembly procedure for reassembly. For reassembly, however, description is added as needed, for example, if the procedure is different from the reversed disassembly procedure or if any precautions are to be taken.

Where any adjustment is to be made in reassembly process, the adjustment procedure is described with the heading “Adjust/Confirm”.

### 3-1-1. Precautions for disassembly and reassembly

Be sure to follow the precautions shown below before starting disassembly and reassembly.

- Be sure to turn off the main power switch (behind the printer) unless otherwise instructed, to prevent human electric shock or circuit damage. (Turning off the power switch on the front panel is insufficient.)
- For disassembly and reassembly, be sure to wear gloves to avoid injury.
- For servicing, place the printer on a firm floor with sufficient space around it.
- Take great care to handle the printer, which is very heavy. At least five persons must cooperate to install or remove the leg assembly to or from the main body.
- Use only the specified tools. (See [P.3-3](#) )
- Do not use any lubricants or adhesives other than specified.
- When handling a PCB assembly, never touch any elements on the PCB assembly with your bare hand; otherwise static electricity may arise to damage elements.  
To touch any element, be sure to use a grounding band.
- In reassembly, put wiring for every electric part in position.  
(Otherwise, a cable may come in contact with a sharp edge or the noise resistance margin may decrease.)
- If it is needed to operate the printer with cover removed, take care not to get injured with any moving part.
- Be very careful to handle cutter blade to avoid human injury or damage of peripheral elements. It is very sharp.
- Be sure to certainly join connectors and FPCs. Be careful to avoid insufficient or skewed insertion.
- To remove a part for which procedure is not described, carefully observe its installation status in advance. Refer to the part catalog as needed.

### 3-1-2. Tools and jigs

Tools to be used at disassembly and reassembly

| Name   | Remarks   |
|--|---|
| Phillips screwdriver<br>Type 1<br>Type 2<br>Type 2 | For M2<br>For M3 to 5 (L=260 or more)<br>for M3 to 5  |
| Slotted screwdriver                                | Long side 2.5 mm for removing E-rings   |
| Hexagon wrench                                     | 1.5 mm for M3 SSWP<br>2.0 mm for M4 SSWP<br>2.5 mm for M3 cap bolts (L=170)<br>5.0 mm for M6 cap bolts<br>6.0 mm for M8 cap bolts |
| Spanner  | Width across flats: 5.0 mm<br>Width across flats: 5.5 mm for M3 nuts and hexagon stud<br>Width across flats: 7.0 mm for M4 nuts   |
| Tweezers   | To prevent the cable from being pulled when disconnecting the connector.  |
| Long-nose pliers                                   |   |
| Nippers  |   |
| Soldering iron                                     |   |
| Solder   |   |
| Scale  | 150, 500 mm   |
| Bar type tension gauge                             | 500 g   |
| Loupe  | About 50x to 60x magnification  |
| Protection glasses                                 |   |
| Gloves   | To keep hands clean, and for safety.  |
| Adhesive agent                                     | LOCKTITE242 (for locking screws)  |
| Insulation lock                                    | L=150 or less (UL-approved product)   |
| Goggle   |   |
| Nitroflon tape or acetate fabric tape              | As required (UL-approved product)   |
| Waste cloth  |   |
| Cotton swab  |   |


Adjustment tools

| Name                           | Code      | Remarks   |
|--------------------------------|-----------|---|
| Trimmer adjustment screwdriver |           | For adjustment of trimmers on the power supply PCB. |
| Tester                         |           |   |
| Bar type tension gauge         |           | 500 g   |
| Ink line airtight tester       | OPT-J0094 |   |

# 3-2. Overhaul of Covers


The cover parts for the JV33-130/160 are as follows.

## Printer Front Panel



Continued to next page ( p.3-5 )

## Printer Rear Panel



Put cover inside the washer of loosened screws to tighten them.

**OK**



The washer of the screw is outside of the cover.

**NG**




The washer of the screw is inside of the cover.

# 3-3. Overhaul of Ink-related Parts



Ink-related parts of the JV33-130/160 are shown below.

| Part  | Reference page |
|---|----------------|
| 3-3-1. Head Unit                                  | p.3-7          |
| 3-3-2. Pump Motor                                 | p.3-12         |
| 3-3-3. Capping Assembly                           | p.3-13         |
| 3-3-4. Major Parts for Washing Cartridge Assembly | p.3-15         |


~ Ink Cartridge ~



~ Head Assembly ~



### 3-3-1. Head Unit



#### □Content

General Procedures and instructions for Head Unit Replacement are described here.

| Item                                     | Description  | Reference page         |
|--|--|------------------------|
| 1. Preparation<br>(Cleaning within Head) | Because the head is filled with water-based transportation liquid (S-46) on shipment, this will react with the solvent ink to form a precipitate. Use S Head Changing Wash (MILD SOLVENT WASHING LIQUID) to clean the head before replacement. | <a href="#">p.3-8</a>  |
| 2. Remove the Head Unit                  | Refer to the video manual  |                        |
| 3. Reassemble Head Unit                  | Refer to the video manual  |                        |
| 4. Filling of Ink                        | Choose ink charge procedure according to change or no-change of Damper, and execute "TEST DRAW" after ink charge is completed.   | <a href="#">p.3-9</a>  |
| 5. Adjustment of the head angle          | Mechanically adjust the angle of Head Unit.  | <a href="#">p.3-9</a>  |
| 6. Drop Position Correction              | Correct dot positions.   | <a href="#">p.3-11</a> |

#### □Tools and Jigs

- IH47V Head unit Assembly (M007034)
- Inside head washing tool (M005027) ←Equivalent to JV3
- Washings for replacement of S-head (M005026) ←Equivalent to JV3 (Only when filling with Solvent Ink)
- Phillips screwdriver (No.2 M3-M5)
- Hexagon wrench (Opposite side: 2.5 mm Bondhus type magnetized)
- Small slotted screwdriver
- Scope (approx. x50)
- Media for adjustment (Glossy type media)
- Waste cloth (non-woven paper, etc.)



**Use protection glasses and gloves during works.**

**In some working conditions, ink may reach your eye or contact with ink may chap your skin.**



The Head Unit Replacement procedure is principally the same as for JV3. Damper construction is the same, while the appearance of the Head is different.

## Preparation (Cleaning within Head)



Washing inside the head is only required when filling with Solvent Ink. Do not wash inside the head when using Aqueous Ink.

### 1 Charge Head Change Washing.

Remove Damper Assembly from Washing Jig in the head, and charge Syringe with 12-16 cc of S-head Change Washing.

\* Confirm the current type of ink when choosing the washing liquid. The type of washing liquid depends on the ink.

Each washing jig is exclusively for use with the corresponding washing liquid. Do not use a jig with a different washing liquid.

~ Types of Wash ~

ES3 Ink:


MILD SOLVENT WASHING LIQUID (SPC-0294)



### 2 Connect Damper to Head.

Reassemble S-damper assembly with Syringe and join it with Damper Connector on Head.


\* Be careful of MS washing liquid dripping on the operation of the damper. Dripping on the FPC connector may damage the head.



### 3 Slowly pour the washing liquid.

Pour 3-4 cc of washing liquid into each nozzle over about 30 seconds.

\* Pour washing liquid slowly, or the Head may be damaged.



### 4 Use waste cloth to receive liquid that spills out of nozzle.


Conduct the above for every nozzle (x8). (Charge the syringe with washing liquid every 4 nozzles.)

\* Do not touch the nozzle surface with waste cloth, nor rub the nozzle surface. Both may cause discharge failure.

## Filling Ink


\* Take the right procedure to save ink and improve work efficiency

- 1 Set media and turn the power ON.
- 2 Execute "FILL UP INK".



## Adjustment of the head angle


- 1 Select "SLANT ADJUST" from the operation menu to execute adjustment pattern drawing.



- 2 Move the head over the platen.
- 3 Move the adjustment lever to adjust the head angle.


Lift up the two AD locking levers to release the lock before moving the adjustment lever.

\* Movement distance of one graduation of the adjustment lever is 40 μm




**4** Adjust the angle using the following procedure.

The a column and b column patterns are printed alternately at a pitch of approximately 100 mm as shown in the figure on the right. The a column and b column can be identified by the magenta and cyan strips (indicates by the thick red arrows in the diagram) printed over the respective patterns at the top of head 1. These indicate that magenta = a column and cyan = b column.




1. Check the inclination of each column.  
For the b column, the relationship between the points of impact and the inclination of the head is as shown in the diagram on the right.




2. Perform an averaging adjustment.  
The standard colors for each column is a column = M, b column = C.  
Move the adjustment lever and adjust the inclination.

In the diagram on the right, the b column is aligned but the a column is misaligned. In this case, adjust such that b becomes slightly misaligned and the degree of scattering of a and b becomes equal. (= intermediate adjustment)



## Drop Position Correction


- 1** Select “DROP.POS ADJUST” from the operation menu.



- 2** Select a scan speed for the standard.

Select standard or high-speed depending on the usage conditions.


\* The factory default is “high-speed”.



- 3** Select the resolution for standard.


\* DRAFT :540dpi  
FINE :720dpi

\* Adjusts all of DRAFT, FINE, DRAFT2, and FINE2.



- 4** Print the “Y return” and “Fine Y return” in order.


After adjusting the Y return, perform fine adjustment of the fine Y return.



- 5** Check the pattern.

■ Y Bi


Check the overlapping parts of the pattern on the outward and return paths.




■ Fine Y Bi

Only Draw is used for the pattern drawing. Use the scope and adjust where the two lines overlap.


Adjusting value: -50~50.0 dot (unit: 0.1 dot)



- 6** Enter the adjustment value.



### 3-3-2. Pump Motor




**1** Remove the station cover (x5 screws). (See [P.3-4](#) )

**2** Remove the head cover (x2 screws). (See [P.3-4](#) )

**3** Remove the pump tube that is connected to the cap head.

**4** Remove the screws (x2) and remove the pump motor assembly.


Remove the connector as well.



**5** Install by reversing the removal procedure.

The pump tube protrudes by approximately 5 mm.

### 3-3-3. Capping Assembly




- 1** Turn the main power supply of the printer off.




Be sure to shut the main circuit breaker to prevent unexpected movements.

- 2** Manually move the head unit over the platen.
- 3** Remove the wiring cover (x6 screws).  
(See [P.3-5](#) )
- 4** Remove the station cover (x5 screws).  
(See [P.3-4](#) )
- 5** Remove the head cover (x2 screws).  
(See [P.3-4](#) )
- 6** Remove the screw (x1) and component.




- 7** Remove the coupler between the capping assembly and tube.
- 8** Remove the screws (x2).
- 9** Remove the capping assembly while turning back the pump washing parts.



- 10** When reattaching, insert the capping assembly into the prescribed position while turning back the pump washing parts at capping upper part.


### 3-3-4. Major Parts for Washing Cartridge Assembly

- 1** Execute [MACHINE SETUP] -[#ADJUST] -[HEAD ADJUST]- [HEAD WASH] to discharge the ink. (See [P.2-21](#) )
- 2** Remove the ICU cover R (x6 screws). (See [P.3-5](#) )




**3** Change the coupler when switching between 4/6 (+white) colors.

The factory default setting is 4-color.




**Ink supply path (4-color fill)**

Use the procedure of next page to change to 6-color.




**Ink supply path (6-color fill)**




**SS 21 Ink supply path (6-color+white fill)**


1. Loosen the coupler screws and remove the tube and O-rings.



2. Put on the rubber plugs on the coupler.  
\* Make sure that O-ring is not remaining in the coupler screws.



3. Tighten the coupler screws.  
Leave the space of around 0.5 mm between the coupler and screw.




## 3-4. Overhaul of PCBs


PCBs to be used for JV33-130/160 are shown below.

| Part            | Reference page | Part               | Reference page |
|-----------------|----------------|--------------------|----------------|
| 3-4-1. Main PCB | p. 3-19        | 3-4-2. Station PCB | p. 3-25        |

~ Left ~



### 3-4-1. Main PCB



#### □Content

In changing Main PCB, parameters must be registered to Main PCB ROM after the change. Because of the time it takes to readjust and reconfigure these settings, and for ease of use and better printing quality, copy the setting value to a PC (upload) before replacement, then write the copied settings back to the main PCB from the PC (download) after replacement.

#### □Tools & jigs

- PC
- F/W UpdateTool
- USB Cable

#### □Work Flow

| Item                             | Description  | Reference page         |
|----------------------------------|--|------------------------|
| 1. Upload Parameters             | Copy the setting values to a PC (upload) before replacing the main PCB.  | <a href="#">p.3-20</a> |
| 2. Remove/Install the main PCB   | Replace Main PCB   | <a href="#">p.3-21</a> |
| 4. Download Parameters           | Write the parameter values that were uploaded in step 1 to the new main PCB.   | <a href="#">p.3-22</a> |
| 5. Adjust Main PCB Motor Current | Adjust the power supply current value to reduce the hunting sound when the X-axis motor and Y-axis motor are driven. | <a href="#">p.3-23</a> |




**If upload of parameters is unavailable, conduct Parameter Draw to note the values. Then manually register them after replacing the Main PCB.**

## Upload Parameters

**1 Start JV33 with parameter Up/Down load Mode.**

Turn the power ON with pressing [**▲**]+[**▼**].



**2 Start FWUpdateTool3.**


Connect the PC and JV33 by USB cable, and run the FWUpdateTool3.



**3 Select the interface in the [Upload] tab of the FW Update Tool III screen.**


In [Device] section, check the interface connecting printer.

**4 Select [JV33.PRM] in the [PRM File] list, then execute [Upload!!].**



**5 The screen in the diagram on the right is shown during uploading.**


Click [Abort] button to cancel.



## 6 Save Parameter File.

Parameter Save Window automatically appears when Upload is successfully completed.

Enter file name to save parameters.



## 7 Turn off the power of JV33.

Confirm the indication shown on the right on Operation Panel of JV33 before shutting down.

Up & Download END  
Power Off



If upload is failed or impracticable, conduct Parameter Draw to note the parameter values and manually register them after the work is completed.

## Removing/Installing the main PCB

### 1 Shut off the main power.




Be sure to shut the main circuit breaker to prevent unexpected move.

### 2 Remove the screws (x6) of the power BOX cover.

### 3 Remove the screws (x6), and remove the main PCB from the front.

### 4 Release the connectors.




### 5 Install by reversing the removal procedure.

## Download Parameters

**1 Start JV33 with parameter Up/Down load Mode.**

Turn the power ON with pressing [**▲**]+[**▼**].



**2 Start the FWUpdateTool3.**

Connect the JV33 and PC by USB cable, and run the FWUpdateTool3.



**3 Select the interface in the [Download] tab of the FW Update Tool III screen.**


In [Device] section, check the interface connecting printer.

**4 Select [JV33.PRM] from the [PRM File] list.**

**5 Select the file to upload.**

Click the [Browse] button, and select the file that was uploaded before replacing the main PCB.

**6 Execute [Download!!]**



**7 The screen in the diagram on the right is shown during downloading.**


Click [Abort] button to cancel.



**8 Check that the operation completed normally.**

A completed dialog box is displayed if the operation completed successfully.

Click [OK] button.



## 9 Turn the JV33 power supply off.

Check that the screen as shown on the right is displayed on the JV33 control panel, then turn the power off.


Up & Download END  
Power Off

## Adjust Main PCB Motor Current

If there is a hunting noise when the X-axis motor and Y-axis motor are driven after replacing the main PCB, adjust the supply current to minimize the hunting noise.


Perform the supply current adjustment while the head is above the station without moving the carriage out.

### 1 Select “STOP ADJUST” from the operation menu in maintenance mode.



### 2 Execute “STOP ADJUST”.

Adjust electric current value of X-axis motor and Y-axis motor so that Hunting noise of both motor is minimized on the station in not carriage out.




### 3 Enter the test conditions and execute “X MOVING ADJUST”.

Input the following conditions.



Speed (S) : 5 ~ 10 mm/s

Acceleration (A) : 0.2 G

Length (X) : approx. 50 ~ 100 mm



[▲]/[▼] : CV  
[◀]/[▶] : MOVE  
[ENTER] : Exec  
[END] : Return




\* Not cap OFF

### 4 Adjust the value to minimize the hunting sound when the X-axis motor is driven.

Check the noise of X-axis motor at the left back side of JV33.

\* Input values with targeting 130~160.  
(Input range 0~255)



[▲]/[▼] : Change adjust value  
[END] : Store adjust value and end

**5 Enter the test conditions and execute “Y MOVING ADJUST”.**

Input the following conditions.

Speed (S) : 5 ~ 10 mm/s

Acceleration (A) : 1.0 G

Length (X) : approx. 50 ~ 100 mm

**6 Adjust the value to minimize the hunting sound when the Y-axis motor is driven.**

Check the noise of Y-axis motor at the right back side of JV33.

\* Input values with targeting 130~160. (Input range 0~255)

**7 Press [END] several times to finish the Y-axis motor current adjustment.**

#MOTOR CURRENT  
Y MOVING ADJUST<ent>



#Y MOVING ADJ.  
S=\*\*\* A=\*\*\* X=\*\*\*\*



Y axis consecutive driving  
(Y axis motor driving)




#Y MOVING ADJ. \*RUN\*  
XXX (\*\*\*\*)

[▲]/[▼] : CV  
[◀]/[▶] : MOVE  
[ENTER] : Exec  
[END] : Return  
(Carriage out)

[▲]/[▼] : Change adjust value  
[END] : Store adjust value and end

### 3-4-2. Station PCB




- 1** Turn the main power supply of the printer off.




Be sure to shut the main circuit breaker to prevent unexpected move.

- 2** Remove the right cover. (See [P.3-4](#) )
- 3** Remove the screws (x4), and remove the station PCB to the front.
- 4** Release the connectors.
- 5** Reverse the disassembly procedure for reassembly.



## 3-5. Overhaul of Sensors

Sensors for JV33-130/160 are shown below.




## 3-6. Overhaul of Driving Parts


Driving parts for JV33-130/160 are shown below.

| Part                       | Reference page |
|----------------------------|----------------|
| 3-6-1. X-axis Motor        | p. 3-28        |
| 3-6-2. Y-axis Motor        | p. 3-31        |
| 3-6-3. Y-axis Drive Pulley | p. 3-35        |
| 3-6-4. Y Drive Belt        | p. 3-39        |
| 3-6-5. Wiper Unit          | p. 3-42        |

~ LEFT ~



### 3-6-1. X-axis Motor



Content

A summary of the series of operations to perform when replacing the X-axis motor, is described along with the procedure.

| Item   | Description  | Reference page         |
|--|--|------------------------|
| 1. Removing/Installing the X-axis motor assembly | Replace the X-axis motor assembly.                           | <a href="#">p.3-29</a> |
| 2. Adjust the X-axis motor current               | Adjust if there is a hunting noise when the motor is driven. | <a href="#">p.3-30</a> |

## Removing/Installing the X-axis motor assembly

- 1 Turn the main power supply of the printer off.




Be sure to shut the main circuit breaker to prevent unexpected movements.

- 2 Remove Left Cover. (See [P.3-5](#) )


- 3 Remove the screws (x2) attached to the XM bracket.

- 4 Remove the X-axis motor connector.

- 5 Remove the spring, and remove the XM bracket and X-axis motor from the main unit.



- 6 Remove the screws (x3) attached to the XM bracket, and remove the X-axis motor assembly.



- 7 Reattach by reversing the removal procedure.




The belt tension does not need to be adjusted.

## Adjust X-Axis Motor Current

If there is a hunting noise when the motor is driven, adjust the power supply current to minimize the hunting noise. Perform the supply current adjustment while the head is over the station, without moving the carriage out.

- 1** Select “X MOVING ADJUST” from the operation menu in maintenance mode.




- 2** Input the following conditions and execute.

Input the following conditions.

Speed (S) : 5 ~ 10 mm/s

Acceleration (A) : 0.2 G

Length (X) : approx. 50 ~ 100 mm




- 3** Adjust the value to minimize the hunting noise when the X-axis motor is driven.

Check the noise of X-axis motor at the left back side of JV33.

\* Input values with targeting 130~160.  
(Input range 0~255)

- 4** Press [END] several times to finish the X-axis motor current adjustment.

### 3-6-2. Y-axis Motor



#### □Content

A summary of the series of operations to perform when replacing the Y-axis motor, is described along with the procedure.

| Item   | Description  | Reference page         |
|--|--|------------------------|
| 1. Removing/Installing the Y-axis motor assembly | Replacing the Y-axis motor assembly.                         | <a href="#">p.3-29</a> |
| 2. Adjusting the Y-axis motor supply current     | Adjust if there is a hunting noise when the motor is driven. | <a href="#">p.3-34</a> |

### Removing/Installing Y-axis Motor Assembly


- 1 Turn the main power of the printer off.



Be sure to shut the main circuit breaker to prevent unexpected move.


- 2 Remove the right cover (x9 screws), and the KB cover (x4 screws). (See [P.3-4](#) )

- 3** Remove the KB bracket screws (x4), then disconnect the connector and remove the keyboard.



- 4** Remove the Y-axis motor cover (right side: 2 screws, left side: 2 screws).


Remove the left side screws (x2) after manually move the head above the platen.



- 5** Loosen the screws (x4) that affix the Y-axis motor belt, and reduce the belt tension.

- 6** Remove the screws (x2) from the top of the Y-axis motor then remove the YM top plate.

- 7** Use pliers or a spanner to remove the YM stat 33 (x2).




- 8** Remove the Y-axis motor assembly while taking care not to drop it.

- 9** Release the 2 clamps and the cable (directly connected to main PCB).

## 10 Reattach by reversing the removal procedure.


\* Attach so that the belt is horizontal and centered on the Y-axis drive pulley (upper side is also acceptable).



## Adjust Y-Axis Motor Current

If there is a hunting noise when the motor is driven, adjust the supply current to minimize the hunting noise. Perform the supply current adjustment while the head is over the station, without moving carriage out.

- 1 Select “Y MOVING ADJUST” from the operation menu in maintenance mode.




- 2 Input test conditions to execute.

Input the following conditions.

Speed (S) : 5 ~ 10 mm/s

Acceleration (A) : 1.0 G

Length (X) : approx. 50 ~ 100 mm




- 3 Adjust the value to minimize the hunting noise while the Y-axis motor is driven.

Check the noise of Y-axis motor at the right back side of JV33.

\* Input values with targeting 130~160.  
(Input range 0~255)

- 4 Press [END] several times to finish the Y-axis motor current adjustment.

### 3-6-3. Y-axis Drive Pulley




- 1** Turn the main power supply of the printer off.




Always ensure that the main power supply is off when the power is off. This procedure is extremely dangerous if the sleep function is mistakenly activated instead.

- 2** Remove the front cover (x4 screws), the Y cover C (x4 screws), the right cover (x9 screws) and the KB cover (x4 screws). (See [P.3-4](#) )
- 3** Remove the KB bracket screws (x4), then disconnect the connector and remove the keyboard.




**4** Remove the Y-axis motor cover (right side: 2 screws, left side: 2 screws).


Manually move the head over the platen before removing the left-side screws (x2).




**5** Remove the screws (x2) that hold the washing cartridge assembly in place, and slide the washing cartridge assembly towards the back.



**6** Remove the screw (x1) from the top of the Y-axis drive pulley.




**7** Loosen the screws (x2) from the Y-SP plate on the left side of the main unit, and release the tension on the Y-axis drive belt.




- 8** Move the head unit over the platen, and remove the head cover (2 screws) and station cover (2 screws) (See P.3-4 )

- 9** Remove the slider rear panel screw (x1), and remove the height lever base assembly.




- 10** Remove the slider rear panel screws (x2), and detach the head unit from the Y-axis drive belt.




- 11** Slide out the connection point of the Y-axis drive belt, and remove either the left or right belt holder 1 from the belt holder.

\* Do not remove the Y-axis drive belt from the slider.




- 12** Remove the screw (x1), and detach the DBKT U from the Y-axis drive pulley.




- 13** Loosen the screws (x4) for fixing the Y-axis motor belt tension, and reduce the tension on the belt. Remove the O-ring from the top of the Y-axis drive pulley, remove the 2 belts, then remove the Y-axis drive pulley.

\* Take care not to lose the O-ring.




- 14** After replacing the Y-axis drive pulley, rotate the Y-axis motor belt approximately two times to check the position of the belt.

\* Attach so that the belt is horizontal and centered on the Y-axis drive pulley (upper side is also acceptable).



- 15** Reverse the disassembly procedure for reassembly.

### 3-6-4. Y Drive Belt




- 1** Turn the main power supply of the printer off.




Be sure to shut the main circuit breaker to prevent unexpected move.


- 2** Remove the front cover (x4 screws), the Y cover C (x4 screws), and the head cover (x2 screws).  
(See [P.3-4](#))
- 3** Remove the slider rear panel screws (x2), and detach from the belt.



- 4 Loosen the screws (x2) of the Y-SP plate on the left side panel, and release the tension from the Y drive belt.




- 5 At the belt connection points, remove the left and right side belt holder 1 from the belt holders.




- 6 Remove the belt holder 1 screws.

- 7 Pry open the belt holder 1 with a slotted screwdriver or similar, then slide to detach from the belt.




- 8 Use rubber tape or similar to stick together the ends of the old belt and the new belt, and perform one revolution of the belt.



- 9 Once the belt has made one revolution, remove the joining tape and pass the belt through the rear side of the slider.

- 10** Align the belt holder 1 and the teeth on the left and right belt ends, and attach the belt holder 1 engaging the teeth and tighten the screw.


Engage the toothed surface of belt with belt holder 1.




Belt holder 1 (M400160)

- 11** Join the left and right belt holder 1 to the belt holder.
- 12** Attach the belt holder and slider using a screw.
- 13** Loosen the screws (x2) on the Y-SP plate on the left side panel of the main unit, and increase the Y drive belt tension.

### 3-6-5. Wiper Unit



- 1 Turn the main power supply on the right side panel of the printer ON, then select [MAINTENANCE] - [ST.MAINTENANCE] - [CARRIAGE OUT] to move the head unit over the platen.




- 2 Turn the main power supply OFF.




Be sure to shut the main circuit breaker to prevent unexpected move.


- 3 Remove the front cover (x4 screws) and the station cover (x5 screws). (See P.3-4)
- 4 Remove station cover 2 (x4 screws).



- 5** Remove the screws (x2), and remove the wiper assembly from the base.




- 6** Release the clamp from the lower part of the station, and remove the connector that is directly connected to the wiper motor.



- 7** Remove the wiper home position sensor connector.

- 8** If you are replacing only the motor, remove the wiper drive link and remove the screws (x2) to remove the motor.

\* When replacing the motor, create a gap of 0.5 mm between the motor and the base.




- 9** Reattach by reversing the removal procedure.


## 3-7. Overhaul of Other Parts

The JV33-130/160 drive system parts are as follows.

| Part                                    | Reference page |
|---|----------------|
| 3-7-1. Cutter Unit Assembly             | p.3-45         |
| 3-7-2. Linear scale                     | p.3-48         |
| 3-7-3. Adjustment of the station height | p.3-50         |



### 3-7-1. Cutter Unit Assembly




#### □Content

A summary of the series of operations to perform when replacing the cutter assembly is described along with the procedure.

| Item                                     | Description  | Reference page         |
|--|--|------------------------|
| 1. Remove/Install Cutter Unit Assembly   | Replace the cutter assembly.   | <a href="#">p.3-45</a> |
| 2. Adjust the cutter attachment position | Use the height adjustment jig to adjust the up/down/left/right attachment positions. | <a href="#">p.3-46</a> |

### Remove/Install Cutter Unit Assembly

- 1** Turn the main power supply on the right side panel of the printer ON, then select [MAINTENANCE] - [ST.MAINTENANCE] - [CARRIAGE OUT] to move the head unit over the platen.




- 2** Turn the main power supply off.



Be sure to shut the main circuit breaker to prevent unexpected movements.

- 3** Remove the front cover (x4 screws), Y cover C (x4 screws), and the head cover (x2 screws). (See [P.3-4](#))

- 4** Remove the screws (x3), then remove the cutter unit.
- 5** Reattach by reversing the removal procedure.




## Cutter Unit Positioning



If the jig cannot be arranged, using an intervenient having height of 7.0 mm of the cutter unit side is allowed.

- 1** Set screws (x3) of the cutter unit at temporary joint state.  
Temporary joint state is that the unit is held lightly.
- 2** Down the Clamp Lever.  
Keep clamp lever down while adjusting. PG setting should be 1.5 mm or less.
- 3** Set the Jig to the Platen.  
Place the jig base pin (x3) in the slots in the back and front for platen media plate.
- 4** Push the jig to the end of the head.  
After setting, slide the jig to the head end (to stop).




## 5 Adjust the cutter unit position back-front.

Decide the unit's lengthwise position so that the cutter tool meets the slot (with push down the cutter tool), and fix it with a screw.

\* Cutter tool positioning slot has width wider than that of the tool. Adjust the position within the range.

\* When there is no jig, push down the cutter tool assembly to the platen face and adjust using the cutter slot of platen.




## 6 Move the head unit to each right, center and left end on the platen, and push down the cutter tool assembly to check back-front positioning.

\* On rare occasions, the tool comes out of the slot because of assembling accident errors or differences of part accuracies. In such a case, adjust again to the back-front optimum position where the tool is always in whole slot on the platen.

## 7 Attach the covers.

Reverse the disassembly procedure for reassembly.

### 3-7-2. Linear scale




While performing work, take care to avoid attaching fingerprints or oil to the linear scale.

(If the linear scale becomes dirty, clean with a neutral detergent.)


Take care also to avoid bends, scratches, etc.

- 1** Remove the front cover (x4 screws), Y cover C (x4 screws), and the maintenance cover (x4 screws). (See [P.3-4](#) )
- 2** Remove the screw from the left end of the linear scale, and remove the linear scale from each of the springs.




- 3** Remove the head cover (x2 screws). (See [P.3-4](#) )

- 4** Remove the screws from the right end of the linear scale, and remove the linear scale.




- 5** Remove the screw from the components at the end (linear encoder), and replace the linear scale.




- 6** Reattach by reversing the removal procedure.

- 7** Move both the media position and the position without media down and carry out a linear encoder test.

\* If the media is too thin to read, use a media within the specifications.




### 3-7-3. Adjustment of the station height




#### Adjustment of the wiper height

- 1** Remove the front cover (x4 screws) and the station cover (x5 screws). (See [P.3-4](#) )
- 2** Loosen the wiper height adjusting screws (x2), and temporarily adjust the screws until the thickness gauge is 8mm.
- 3** Loosen the screws (x2) on the front of the head cover, and then tighten the screws while holding the height adjustment lever in the lowest position to fix the head in place.




- 4** Move the head, and adjust the wiper so that there is approximately 1 mm from the nozzle surface.




## Adjustment of the station base height

**1** Remove the front cover (x4 screws) and the station cover (x5 screws). (See [P.3-4](#) )

**2** Loosen the station base adjusting screws (x2).



**3** Loosen the hexagonal-hole set screw using a spanner or monkey wrench, then adjust until the thickness gauge is 5 mm and tighten the nut.



**4** Tighten the adjustment screws (x2) to lock in place.



# CHAPTER 4 Troubleshooting

---

---

## **Contents**

|  |            |
|--|------------|
| <b>4-1. Outline .....</b>  | <b>4-2</b> |
| 4-1-1. Rough identification of the source of the trouble ....    | 4-2        |
| 4-1-2. Checking procedure .....                                  | 4-2        |
| <b>4-2. Troubles for which error messages are displayed ....</b> | <b>4-4</b> |
| 4-2-1. Error messages and corrective measures .....              | 4-4        |
| 4-2-2. Warning messages and corrective measures .....            | 4-10       |



## 4-1. Outline

This chapter describes the troubleshooting for JV33-130/160. Before starting work, read and understand thoroughly the instructions given below and “1-1. Precautions in Maintenance” (p.1-2).

### 4-1-1. Rough identification of the source of the trouble

At the beginning of troubleshooting, it is necessary to identify the trouble roughly which functions the trouble relates to.


Problems can be roughly classified into those that relate to the printer itself and those that involve the connection between the printer and the host computer.

1. Problems with the printer itself  
The cause of the trouble can be identified by executing appropriate functions or using test functions.
2. Problems concerning the connection to the host computer  
Hardware: Broken wire or faulty contact of cables  
Software: Transmission by improper application setting



In the standard setting of JV33-130/160, priority is given to the host computer. Check the settings on the host computer to see if there is any improper parameter setting.

### 4-1-2. Checking procedure



This section describes troubleshooting procedures for the problems for which error messages are displayed.

## **1. Identifying the error category**

---

The causes of errors can be classified into the following categories:

- Handling error on the host computer side
- Trouble on the host computer side
- Trouble with the interface cable
- Printer handling error
- Printer mechanical trouble
- Printer hardware trouble
- Printer firmware trouble

## **2. Initial action**

---

Refer to the error message, and judge whether the trouble lies on the host computer side or on the printer side.

- Has any of the interface conditions (Printer model setting, command, communication conditions, etc.) been changed?
- Does the trouble occur under specific conditions?
- Does the same trouble occur repeatedly?

## **3. Failure on the printer side**

---

Take the following steps to repair the printer.

- Replace the defective part (sensor, etc.) or make the necessary adjustment.
- Replace the main PCB.

## **4. Repair at the factory**

---

If the error recurs even after the corrective measures specified here are taken, return the printer to the factory of MIMAKI for repair.

## 4-2. Troubles for which error messages are displayed

### 4-2-1. Error messages and corrective measures

<Error messages and corrective measures >

| Display   |                | Cause   | Remedy (instruction & maintenance manual)  |   |
|-----------|----------------|---|--|---|
| ERROR No. | ERROR          |   | Descriptions in the manual (for reference)   | Remedy  |
| ERROR 01  | MAIN ROM       | An error occurred on the control circuit board. (ROM)                             | Turn the main power OFF and turn the main power ON after elapse of 2~3 minutes. In a case of recurrence, contact your local distributor to call for service. | 1. Replace the main PCB with a new one.   |
| ERROR 02  | MAIN RAM       | An error occurred on the control circuit board. (RAM)                             | Turn the main power OFF and turn the main power ON after elapse of 2~3 minutes. In a case of recurrence, contact your local distributor to call for service. |   |
| ERROR 03  | POWER +5V      | An error occurred on the control circuit board. (Power supply voltage +5V)        | Turn the main power OFF and turn the main power ON after elapse of 2~3 minutes. In a case of recurrence, contact your local distributor to call for service. | 1. Replace the power supply PCB with a new one.<br>2. Replace the main PCB with a new one.  |
|           | POWER +24V     | An error occurred on the control circuit board. (Power supply voltage +24V)       |  |   |
|           | POWER +42V     | An error occurred on the control circuit board. (Power supply voltage +42V)       |  |   |
| ERROR 04  | FLASH ROM      | An error occurred on the control circuit board. (Parameter ROM)                   | Turn the main power OFF and turn the main power ON after elapse of 2~3 minutes. In a case of recurrence, contact your local distributor to call for service. | 1. After uploading parameters, initialize all parameters.<br>* If the state is not restored, replace the main PCB with a new one.   |
| ERROR 06  | SD-RAM         | An error occurred on the control circuit board. (SDRAM)                           | Turn the main power OFF and turn the main power ON after elapse of 2~3 minutes. In a case of recurrence, contact your local distributor to call for service. | 1. Replace the main PCB with a new one.<br>2. Replace the PRAM PCB with a new one.  |
| ERROR 07  | HEAD (----)    | An error was detected in the head connection. (Abnormal temperature was detected) | Turn the main power OFF and turn the main power ON after elapse of 2~3 minutes. In a case of recurrence, contact your local distributor to call for service. | 1. Reconfirm the head temperature with [#TEST] - [TEMPERATURE.CHK] - [NOZZLE TEMP].<br>In case of recurrence, execute the followings.<br>2. Make sure that corresponding FPC, main FPC are connected in the right way.<br>3. Replace the corresponding head with a new one.<br>4. Replace the ink slider PCB with a new one.<br>5. Replace the main PCB with a new one. |
|           | VOLTAGE (----) | An error was detected in the head connection. (Abnormal voltage was detected)     |  |   |

<Error messages and corrective measures (continued)>

| Display   |                        | Cause   | Remedy (instruction & maintenance manual)  |  |
|-----------|------------------------|---|--|--|
| ERROR No. | ERROR                  |   | Descriptions in the manual (for reference)   | Remedy   |
| ERROR 08  | LinearEN-CODER: SENSOR | An error occurred in detection by the linear encoder.<br>(Counting impossible)  | Turn the main power OFF and turn the main power ON after elapse of 2~3 minutes. In a case of recurrence, contact your local distributor to call for service. | 1. Make sure that linear encoder scale and encoder PCB are placed in the right positions.<br>2. Replace the encoder PCB with a new one.  |
|           | LinearEN-CODER: DIR.   | An error occurred in detection by the linear encoder.<br>(Wrong orientation)    |  |  |
|           | LinearEN-CODER: COUNT  | An error occurred in detection by the linear encoder.<br>(Read-out count error) |  |  |
| ERROR 09  | FPGA ERROR             | An error occurred on the control circuit board.<br>(FPGA PDC)                   | Turn the main power OFF and turn the main power ON after elapse of 2~3 minutes. In a case of recurrence, contact your local distributor to call for service. | 1. Replace the main PCB with a new one.  |
|           | HDC ERROR (----)       | An error occurred on the control circuit board.<br>(FPGA HDC)                   |  | 1. Replace the main PCB with a new one.  |
| ERROR 10  | COMMAND ERROR          | The printer received some data other than command data.                         | Securely connect the interface cable in position.<br>Use an interface cable conforming to the specifications.  | 1. When the state is not recovered even if untreated data is cleared, execute the followings.<br>2. Check the USB cable. (specifications, cable length, etc.)<br>3. Replace the main PCB with a new one. |
| ERROR 11  | PARAMETER ERROR        | Any parameter outside the range of acceptable numeric values was received.      | Turn the main power OFF and turn the main power ON after elapse of 2~3 minutes. In a case of recurrence, contact your local distributor to call for service. | 1. When the state is not recovered even if untreated data is cleared, execute the followings.<br>2. Check the USB cable. (specifications, cable length, etc.)<br>3. Replace the main PCB with a new one. |
| ERROR 12  | MAINTENANCE COMMAND    | –   | (This error does not occur on site.)   | 1. When the state is not recovered even if untreated data is cleared, execute the followings.<br>2. Check the USB cable. (specifications, cable length, etc.)<br>3. Replace the main PCB with a new one. |
| ERROR 16  | MRL COMMAND            | Received data does not follow the command system set in the device.             | Transmit data with the command system corresponding to the system.   | 1. Make sure that the transmission data is in MRL-III command system (data ripped for JV-33).<br>2. Check the command system set with [MACHINE SETUP] - [MRL COMMAND].                                   |

## &lt;Error messages and corrective measures (continued) &gt;

| Display   |                  | Cause  | Remedy (instruction & maintenance manual)   |  |
|-----------|------------------|--|---|--|
| ERROR No. | ERROR            |  | Descriptions in the manual (for reference)  | Remedy   |
| ERROR 25  | FULL-SPEED       | An error occurred in communication between the host computer and the interface board for USB2.0 connection. (Full-Speed mode connection) | Check that the host PC supports the USB2.0 interface. (Communication can be resumed without changing any setting. However, it is recommended to use the connection in High-Speed mode.) | Make sure that the host PC and the USB cable follow the USB2.0 interface standard.   |
|           | PACKET SIZE OVER | An error occurred in communication between the host computer and the interface board for USB2.0 connection.                              | Make sure that the cables are connected correctly and there is no occurrence of an error in the host PC.  | 1. Make sure that the connection to the host PC is correct.<br>2. Make sure that there is no occurrence of an error in the host PC, or the application runs normally.                      |
|           | USB PROTOCOL     | An error occurred in communication between the host computer and the interface board for USB2.0 connection.                              |   |  |
|           | USB ENVIRONMENT  | An error occurred in communication between the host computer and the interface board for USB2.0 connection.                              |   |  |
|           | USB DATA         | An error occurred in communication between the host computer and the interface board for USB2.0 connection.                              |   |  |
|           |                  |  |   |  |
| ERROR 30  | OPERATION ERROR  | Improper operation was conducted on the operation panel.   | Perform correct operations.   | 1. It is notified that wrong operation is conducted.   |
| ERROR 34  | DATA REMAIN      | As received data which is not drawn remains, setting of Function Feature can not be changed.   | Change setting function after executing all received data or clearing the data.   | 1. Explain that any of the operating conditions cannot be changed if data that have not been drawn remains.  |
| ERROR 40  | MOTOR ALARM X    | The X-axis motor was overloaded.   | Turn the main power OFF and turn the main power ON after elapse of 2~3 minutes. In a case of recurrence, contact your local distributor to call for service.                            | 1. Check friction of X-axis motor.<br>2. Replace the X-axis motor with a new one.<br>3. Replace the regenerative resistance PCB with a new one.<br>4. Replace the main PCB with a new one. |
| ERROR 41  | MOTOR ALARM Y    | The Y-axis motor is overloaded.  | Turn the main power OFF and turn the main power ON after elapse of 2~3 minutes. In a case of recurrence, contact your local distributor to call for service.                            | 1. Check friction of Y-axis motor.<br>2. Replace the Y-axis motor with a new one.<br>3. Replace the regenerative resistance PCB with a new one.<br>4. Replace the main PCB with a new one. |
| ERROR 42  | X OVER CURRENT   | Overcurrent in the X-axis motor was detected.  | Turn the main power OFF and turn the main power ON after elapse of 2~3 minutes. In a case of recurrence, contact your local distributor to call for service.                            | 1. Check friction of X-axis motor.<br>2. Replace the X-axis motor with a new one.<br>3. Replace the regenerative resistance PCB with a new one.<br>4. Replace the main PCB with a new one. |
| ERROR 43  | Y OVER CURRENT   | Overcurrent in the Y-axis motor was detected.  | Turn the main power OFF and turn the main power ON after elapse of 2~3 minutes. In a case of recurrence, contact your local distributor to call for service.                            | 1. Check friction of Y-axis motor.<br>2. Replace the Y-axis motor with a new one.<br>3. Replace the regenerative resistance PCB with a new one.<br>4. Replace the main PCB with a new one. |

<Error messages and corrective measures (continued) >

| Display   |                     | Cause   | Remedy (instruction & maintenance manual)  |  |
|-----------|---------------------|---|--|--|
| ERROR No. | ERROR               |   | Descriptions in the manual (for reference)   | Remedy   |
| ERROR 45  | CAPPING : PARAMETER | An error occurred in capping control. (Improper parameter adjusted value)             | Turn the main power OFF and turn the main power ON after elapse of 2~3 minutes. In a case of recurrence, contact your local distributor to call for service. | 1. Make sure that the adjusting value of [#ADJUST] - [CAPPING] is set correctly.   |
| ERROR 46  | WIPER               | An error occurred in wiper control.   | Turn the main power OFF and turn the main power ON after elapse of 2~3 minutes. In a case of recurrence, contact your local distributor to call for service. | 1. Check that the wiper sensor functions properly with [#TEST] - [SENSOR TEST].<br>2. Check that the wiper motor functions properly with [#TEST] - [MOTOR TEST].<br>3. Make sure that there is no friction on the guide rail caused by sticking of ink.<br>4. Replace the wiper sensor with a new one.<br>5. Replace the stepping motor with a new one.<br>6. Replace the station PCB with a new one.  |
| ERROR 50  | MEDIA DETECT        | Paper could not be detected.<br>The media set position or media itself is not proper. | If the same error message appears again even after setting the media properly, contact your local distributor to call for service.                           | 1. Make sure that there is no gap between the end faces of platen and platen rubber.<br>2. Execute [#TEST] - [PAPER SENSOR] to obtain sensor values at the media exist position and media non-exist position. When the difference of values is more than $\pm 50$ , detection is allowed. If the difference is smaller, execute the followings.<br>3. Clean the paper width sensor or replace with a new one.<br>4. Replace the ink slider PCB with a new one. |
| ERROR 51  | Y-ORIGIN            | Y-origin could not be detected.   | Turn the main power OFF and turn the main power ON after elapse of 2~3 minutes. In a case of recurrence, contact your local distributor to call for service. | 1. Check that the Y origin sensor works properly with [#TEST] - [SENSOR TEST].<br>2. Replace the Y origin sensor with a new one.<br>3. Replace the station PCB with a new one.   |
| E70       | FPGA                | FPGA Configuration fails.   | <i>(As the support functions will be supported after the releasing, this error does not arise on site in the present.)</i>                                   | 1. Replace the main PCB with a new one.  |
| E71       | SD-RAM              | Abnormal operation in SD-RAM  | <i>(As the support functions will be supported after the releasing, this error does not arise on site in the present.)</i>                                   | 1. Make sure that PRAM PCB is connected properly.<br>2. Replace the PRAM PCB or main PCB with a new one.   |
| E74       | TRANS DATA          | Received data is not Version Up file  | <i>(As the support functions will be supported after the releasing, this error does not arise on site in the present.)</i>                                   | 1. Make sure that the ROM file is transmitted.   |
| E80       | ROM0 ERASE          | ROM0 Erase error  | <i>(As the support functions will be supported after the releasing, this error does not arise on site in the present.)</i>                                   | 1. Replace the main PCB with a new one.  |
| E81       | ROM1 ERASE          | ROM1 Erase error  | <i>(As the support functions will be supported after the releasing, this error does not arise on site in the present.)</i>                                   | 1. Replace the main PCB with a new one.  |
| E82       | h'*****             | ROM0 Write error  | <i>(As the support functions will be supported after the releasing, this error does not arise on site in the present.)</i>                                   | 1. Replace the main PCB with a new one.  |
| E83       | h'*****             | ROM1 Write error  | <i>(As the support functions will be supported after the releasing, this error does not arise on site in the present.)</i>                                   | 1. Replace the main PCB with a new one.  |

<Error messages and corrective measures (continued) >

| Display   |                        | Cause  | Remedy (instruction & maintenance manual)  |   |
|-----------|------------------------|--|--|---|
| ERROR No. | ERROR                  |  | Descriptions in the manual (for reference)   | Remedy  |
| E84       | h*****                 | Verify error   | <i>(As the support functions will be supported after the releasing, this error does not arise on site in the present.)</i>                                   | 1. Replace the main PCB with a new one.   |
| E85       | ROM HASH               | Hash check error   | <i>(As the support functions will be supported after the releasing, this error does not arise on site in the present.)</i>                                   | 1. Replace the main PCB with a new one.   |
| E90       | h*****                 | ROM Erase error  | <i>(As the support functions will be supported after the releasing, this error does not arise on site in the present.)</i>                                   | 1. Replace the main PCB with a new one.   |
| E92       | h*****                 | ROM Write error  | <i>(As the support functions will be supported after the releasing, this error does not arise on site in the present.)</i>                                   | 1. Replace the main PCB with a new one.   |
| E95       | MODE SHIFT             | Transition to the version up mode is not allowed.                                | <i>(As the support functions will be supported after the releasing, this error does not arise on site in the present.)</i>                                   | 1. Replace the main PCB with a new one.   |
| E99       | VERSION DATA           | Wrong version data.  | <i>(As the support functions will be supported after the releasing, this error does not arise on site in the present.)</i>                                   | —   |
| ERROR 120 | ENVIRONMENT TEMP(LO)   | The ambient temperature is outside the permissible temperature range (too low).  | Adjust the ambient temperature of the printer.<br>To continue operation without changing the ambient conditions, press the [ENTER] key.                      | Operation under the temperature among the guaranteed operation temperature range is recommended.  |
| ERROR 121 | ENVIRONMENT TEMP(HI)   | The ambient temperature is outside the permissible temperature range (too high). |  |   |
| ERROR 144 | CARTRIDGE SET !        | An ink cartridge is not set.   | Set an ink cartridge.  | It is explained that leaving a state without setting a ink cartridge may cause inability of ink sucking because needles of the slot are dehydrated.                       |
|           | ERROR COMMAND          |  | <i>(This error does not occur on site.)</i>  | Confirm the USB cable. (specifications, cable length and so on)   |
|           | ERROR PARAMETER        |  | <i>(This error does not occur on site.)</i>  | Make sure that PRM file, parameter data correspond to version of the device.  |
|           | ERROR DATA             |  | <i>(This error does not occur on site.)</i>  | Confirm the USB cable. (specifications, cable length and so on)   |
|           | ERR PRM. SHORTAGE      |  | <i>(This error does not occur on site.)</i>  | Make sure that PRM file, parameter data correspond to version of the device.  |
| ERROR 200 | HEAD MEMORY (----)     | An error occurred in head unit memory.   | Turn the main power OFF and turn the main power ON after elapse of 2~3 minutes. In a case of recurrence, contact your local distributor to call for service. | 1. Check the head memory cable.<br>2. Replace the head memory with a new one.<br>3. Replace the ink slider PCB with a new one.<br>4. Replace the main PCB with a new one. |
| ERROR 211 | HeaterTEMP (--/--)     | An abnormal temperature of the media heater is detected.                         | Turn the main power OFF and turn the main power ON after elapse of 2~3 minutes. In a case of recurrence, contact your local distributor to call for service. | 1. Replace the main PCB with a new one.<br>2. Replace the power supply PCB with a new one.<br>3. Replace the corresponding platen cover with a new one.                   |
|           | HeadWARM. TEMP. (----) | An abnormal temperature of the head heater was detected.                         |  | 1. Make sure that the connection to the main FPC is correct.<br>2. Replace the corresponding head heater with a new one.  |
|           | HeadWARM. BREAK(----)  | The head heater is disconnected.   |  | 3. Replace the ink slider PCB with a new one.   |
|           | HeadWARM. THERM(----)  | Trouble has occurred with the thermistor of the head heater.                     |  |   |

<Error messages and corrective measures (continued) >

| Display   |               | Cause  | Remedy (instruction & maintenance manual)  |  |
|-----------|---------------|--|--|--|
| ERROR No. | ERROR         |  | Descriptions in the manual (for reference)   | Remedy   |
| ERROR 250 | Y COORDINATES | An error was detected during scanning operation. | Turn the main power OFF and turn the main power ON after elapse of 2~3 minutes. In a case of recurrence, contact your local distributor to call for service. | <ol style="list-style-type: none"> <li>1. Make sure that the position of media is correct.</li> <li>2. make sure that there is no bend on the Paper width sensor.</li> <li>3. When the state is not recovered, check parameter upload and using state, and report the result to the development department.</li> </ol> |
| ERROR 251 | SYSTEM ERROR  | A system error occurred.                         | Turn the main power OFF and turn the main power ON after elapse of 2~3 minutes. In a case of recurrence, contact your local distributor to call for service. | <ol style="list-style-type: none"> <li>1. Confirm the error with memory check (Main.FROM).</li> <li>2. When the state is not recovered, check parameter upload and using state, and report the result to the development department.</li> </ol>  |

## 4-2-2. Warning messages and corrective measures

## &lt;Warning messages and corrective measures &gt;

| Display                             | Cause  | Remedy (instruction & maintenance manual)  |  |
|-------------------------------------|--|--|--|
|                                     |  | Descriptions in the manual (for reference)   | Remedy   |
| Close a cover.                      | An open cover was detected.  | Check the front cover and maintenance covers.<br>If the same error message appears again even after closing all the covers, contact your local distributor to call for service.  | <ol style="list-style-type: none"> <li>1. Make sure that the cover sensor works properly with [#TEST]- [SENSOR TEST].</li> <li>2. Make sure that the toggle pushes the lever of the cover sensor firmly.</li> <li>3. Make sure that the cables are connected properly.</li> <li>4. Replace the cover sensor with a new one.</li> </ol> |
| <LOCAL.1> [#01]<br>** NO MEDIA **   | No media was detected.   | Set media.   | <ol style="list-style-type: none"> <li>1. Check that the paper sensor R works properly with [#TEST] - [SENSOR TEST].</li> <li>2. Make sure that connection of the cables is correct.</li> <li>3. Replace the paper sensor R with a new one.</li> </ol>   |
| !EXCHANGE BATTERY                   | The battery of RTC has run down.   | Contact your local distributor to call for service.  | <ol style="list-style-type: none"> <li>1. Replace the battery with a new one having the same model number.</li> </ol>  |
| <LOCAL.1> [#01]<br>!Replace a WIPER | Time to replace the wiper in the capping station with a new one has come.<br>(The wiping count has reached the specified value.) | Replace the wiper with a new one.<br>* Execute [ST.MAINTENANCE] - [WIPER EXCHANGE].  | <ol style="list-style-type: none"> <li>1. Make sure that wiper replacement is conducted with [MAINTENANCE] - [ST.MAINTENANCE].</li> </ol>  |
| <LOCAL.1> [#01]<br>!Do TEST DRAW    | The nozzle recovery cannot be expected because the printer has been left standing for a prolonged period of time.                | Perform TEST DRAW, and check for omitted nozzles.<br>If nozzles are omitted, perform cleaning. If nozzle missing is serious, execute [ST.MAINTENANCE] - [NOZZLE WASH] for maintenance.   | ←  |
| PRE PRT AFT<br>BREAK **°C **°C      | A heater is disconnected.<br>(This example shows that pre-heater is disconnected.)   | Contact your local distributor to call for service.  | <ol style="list-style-type: none"> <li>1. Check that the heaters work properly with [#TEST] - [HEATER TEST].</li> <li>2. Make sure that connection of the cables is correct.</li> <li>3. Make sure that fuse of power supply PCB is not blown out.</li> <li>4. Replace the power supply PCB or main PCB with a new one.</li> </ol>     |
| PRE PRT AFT<br>THERM **°C **°C      | The thermistor of a heater is defective.<br>(This example shows that the thermistor of pre-heater is defective.)                 | Contact your local distributor to call for service.  | <ol style="list-style-type: none"> <li>1. Check that the heaters work properly with [#TEST] - [HEATER TEST].</li> <li>2. Make sure that connection of thermistor is correct.</li> <li>3. Replace the main PCB with a new one.</li> </ol>   |
| <LOCAL.1> [#01]<br>NEAR END MCKYK   | Ink for one supply path has been nearly used up.   | Replace the ink cartridge for the supply path corresponding to the indicated color.<br>* Printing is permitted without replacing the ink cartridge (until INK END is displayed). However, the printer returns to local mode every completion of printing one file. | ←  |
| *REMOTE.1* [#01]<br>NEAR END MCKYK  |  |  |  |

<Warning messages and corrective measures (continued)>

| Display                          | Cause  | Remedy (instruction & maintenance manual)  |  |
|----------------------------------|--|--|--|
|                                  |  | Descriptions in the manual (for reference)   | Remedy   |
| <LOCAL.1> [#01]<br>INK END MCYK  | Ink for one supply path has been completely used up.   | Replace the ink cartridge for the supply path corresponding to the indicated color.  | ←  |
| *REMOTE.1* [#01]<br>INK END MCYK |  |  |  |
| <LOCAL.1> !CART [#01]            | There is a problem with installed ink cartridges.<br>(If this occurs together with any other warning, the display shows [<LOCAL.1> !CAR/WASH] instead of [##*].)                 | Check the content of the warning by displaying it using the guidance function.   | ←  |
| *REMOTE.1* !CART [#01]           |  |  |  |
| <LOCAL.1> !WASH [#01]            | There is a problem with the installed washing solution cartridge.<br>(If this occurs together with any other warning, the display shows [<LOCAL.1> !CAR/WASH] instead of [##*].) | Check that the washing solution cartridge has been set properly.   | ←  |
| *REMOTE.1* !WASH [#01]           |  |  |  |
| INK NEAR END<br>MMCC ----        | The ink of the ink cartridge has been nearly used up.  | Replace the ink cartridge generating the warning with a new one.   | 1. Check that the cartridge end sensor works properly with [#TEST] - [INK CARTRIDGE].<br>2. Check the end board of the cartridge.<br>3. Replace the sensor with a new one.   |
| INK END<br>MMCC ----             | The ink of the ink cartridge has been completely used up.  | Replace the ink cartridge generating the warning with a new one.   | 1. Check the end board of the cartridge.<br>2. Replace the sensor with a new one.  |
| NON-ORIGINAL INK<br>MMCC ----    | The ink cartridge is not MIMAKI genuine.<br>Or, the ink IC chip can not be read.   | Replace the warned ink cartridge with a MIMAKI genuine one, or insert the ink cartridge again.   | 1. Make sure that [#TEST] - [INK CARTRIDGE] - [INK-IC CHECK] is performed properly.<br>2. Replace the ID point of contact PCB with a new one.  |
| WRONG INK IC<br>MMCC ----        | The IC chip of the ink cartridge cannot be read normally.  | Remove the ink cartridge generating the warning once and install it again.<br>If the same warning message still appears, contact your local distributor to call for service. | 1. Make sure that [#TEST] - [INK CARTRIDGE] - [INK-IC CHECK] is performed properly.<br>2. Replace the ID point of contact PCB with a new one.  |
| Kind of INK<br>MMCC ----         | The ink of the ink cartridge is different in type from the ink currently supplied.   | Check the ink type of the ink cartridge generating the warning.  | ←  |
| Color of INK<br>MMCC ----        | The ink of the ink cartridge is different in color from the ink currently supplied.  | Check the ink color of the ink cartridge generating the warning.   | ←  |
| WRONG CARTRIDGE<br>MMCC ----     | There is trouble with an installed ink cartridge.  | Check the ink cartridge generating the warning.  | ←  |
| NO CARTRIDGE<br>MMCC ----        | An ink cartridge has not been installed in the slot.   | Install an appropriate ink cartridge in the slot generating the warning.   | If the error occurs frequently after replacing ink cartridges, execute the followings.<br>1. Check that the cartridge exist/non-exist sensor works properly with [#TEST] - [INK CARTRIDGE].<br>2. If it does not work properly, replace the sensor or X-axis motor relay PCB with a new one. |
| Expiration<br>MMCC ----          | The specified expiration date of an ink cartridge has passed.  | Replace the ink cartridge generating the warning with a new one.<br>* The ink cartridge may be used until one month passes after the specified expiration date.              | ←  |

## &lt;Warning messages and corrective measures (continued) &gt;

| Display  | Cause  | Remedy (instruction & maintenance manual)   |   |
|--|--|---|---|
|  |  | Descriptions in the manual (for reference)  | Remedy  |
| <b>Expiration:1MONTH</b><br><b>MMCC - - - -</b>            | The expiration date of an ink cartridge has passed (one month has passed after the specified expiration date).   | The red LED blinks.<br>Replace the ink cartridge generating the warning with a new one.<br>* The ink cartridge may be used until two months pass after the specified expiration date. | ←   |
| <b>Expiration:2MONTH</b><br><b>MMCC - - - -</b>            | The expiration date of an ink cartridge has passed (two months have passed after the specified expiration date). | Replace the ink cartridge generating the warning with a new one.  | ←   |
| <b>INK REMAIN ZERO</b><br><b>MMCC - - - -</b>              | Remaining amount of ink in an ink cartridge is zero.   | Replace the ink cartridge generating the warning with a new one.  | ←   |
| <b>!WASTE TANK</b>   | The waste ink tank is nearly full.   | Replace the waste ink tank with a new one.  | 1. Make sure that [MAINTENANCE] - [WasteInkWarning] is performed.   |
| <b>!Wash Liquid END</b>                                    | The washing solution cartridge is empty.   | Replace the washing solution cartridge with a new one.  | 1. Check that the cartridge end sensor works properly with [#TEST] - [WASH CARTRIDGE].<br>2. If it does not work properly, replace the sensor or IO PCB with a new one.             |
| <b>!WashLiquidCart.NONE</b>                                | The washing solution cartridge has not been installed.   | Install the washing solution cartridge.   | 1. Check that the cartridge exist/non-exist sensor works properly with [#TEST] - [WASH CARTRIDGE].<br>2. If it does not work properly, replace the sensor or IO PCB with a new one. |
| <b>!WRONG WASH CART.</b>                                   | There is trouble with washing solution cartridge.  | Check the washing solution cartridge.   | ←   |
| <b>** Washing liquid **</b><br><b>** un-filling up. **</b> | Washing solution has not been supplied.  | Supply the washing solution.<br>Execute [MAINTENANCE] - [HD.MAINTENANCE] - [FILL UP INK].   | ←   |

# CHAPTER 5 Explanation of Electrical Parts

---

---

## **Contents**

|  |             |
|--|-------------|
| <b>5-1. Outline</b> .....                      | <b>5-2</b>  |
| 5-1-1. Operation Explanation .....             | 5-3         |
| 5-1-2. Power Supply .....                      | 5-4         |
| <b>5-2. Circuit Board Specifications</b> ..... | <b>5-6</b>  |
| 5-2-1. Main PCB .....                          | 5-6         |
| 5-2-2. PRAM PCB .....                          | 5-7         |
| 5-2-3. Station PCB .....                       | 5-7         |
| 5-2-4. X-axis motor relay PCB .....            | 5-8         |
| 5-2-5. Ink slider PCB .....                    | 5-9         |
| 5-2-6. Keyboard PCB .....                      | 5-9         |
| 5-2-7. Encoder PCB .....                       | 5-9         |
| 5-2-8. Take-up PCB .....                       | 5-9         |
| 5-2-9. Head memory PCB .....                   | 5-10        |
| 5-2-10. LED PCB .....                          | 5-10        |
| <b>5-3. Electronic block diagram</b> .....     | <b>5-11</b> |



# 5-1. Outline

JV33-130/160 is provided with the circuit boards shown below.

| Part                          | Reference page | Part                   | Reference page |
|-------------------------------|----------------|------------------------|----------------|
| 5-2-1. Main PCB               | p. 5-6         | 5-2-6. Keyboard PCB    | p. 5-9         |
| 5-2-2. PRAM PCB               | p. 5-7         | 5-2-7. Encoder PCB     | p. 5-9         |
| 5-2-3. Station PCB            | p. 5-7         | 5-2-8. Take-up PCB     | p. 5-9         |
| 5-2-4. X-axis motor relay PCB | p. 5-8         | 5-2-9. Head memory PCB | p. 5-10        |
| 5-2-5. Ink slider PCB         | p. 5-9         | 5-2-10. LED PCB        | p. 5-10        |




Fig. 5-1

### 5-1-1. Operation Explanation

- The JV33-160/130 slider has 1 head with 180 nozzles (180 dpi intervals) x 8 rows.
- Ink is ejected from the ink chamber by vibrating the piezoelectric elements of the heads. For this vibration waveform, the printer uses variable waveform which can permit 4-step expressions (L, M, S and none).
- The head is connected to the main PCB in the electrical box, and it is driven by a drive signal (COM waveform) applied to the piezo of 1 nozzle row for each of the eight rows of nozzles. FPGA (HDC) is mounted on Main PCB. The FPGA (HDC) applies the COM waveform in synchronization with the scale interval of the linear scale and simultaneously sends the nozzle data to the head.  
In addition, the COM waveform is automatically corrected based on the registered head ID or the ID registered in the head memory, other information, and the ambient air temperature detected.
- The main PCB has FPGA (PDC), which takes charge of image processing and controls the SDRAM picture memory (PRAM). The PRAM is mounted on the PRAM PCB. The PRAM board has a capacity of 128 MB. Of the data output from the host PC, the command part is analyzed by the CPU and the image part is transferred to the memory. The PRAM is a ring memory and when data for one scanning session has been accumulated, the heads start scanning. One scanning session forms an image only in 180 dpi (6-colors) or in 360 dpi (4-colors) in the X direction. Therefore, the printer completes the image in the targeted resolution while feeding the media by a required distance.
- Since the JV33 is equipped with many IOs (step motors and sensors), if all were connected directly to the main PCB, routing the wiring and replacing the PCB would be difficult. To avoid this, a station PCB and X-axis motor relay PCB are used, reducing the number of signals exchanged with the main PCB using a serial connection. The signals are processed by the FPGA (IOC) mounted on the main PCB.

#### Nozzle Arrangement of Head (Rear View)




Fig.5-2

## 5-1-2. Power Supply

- Board name: Power supply PCB assembly (E300474)
- The input value and output values of power supply are as follows:

|               |  |
|---------------|--|
| <b>Input</b>  | AC100 - 120V, AC220 - 240V, 50/60Hz  |
| <b>Output</b> | +3.3SBV, 5.5 A<br>+5SBV, 1.0 A<br>+5V, 4.2 A<br>+24V, 5.0 A<br>+42V, 4.0 A |

### <AC input connector> (CN1)

Model number (JST) : B2P3-VH (LF) (SN)

| PIN | Terminal name | Type            |
|-----|---------------|-----------------|
| 1   | AC-L          | AC input supply |
| 2   | (NC)          | (NC)            |
| 3   | AC-N          | AC input supply |

### <AC HEAT input connector> (CN2)

Model number (JST) : B03P-VL \* Media heater power input

| PIN | Terminal name | Type            |
|-----|---------------|-----------------|
| 1   | AC-L          | AC input supply |
| 2   | (NC)          | (NC)            |
| 3   | AC-N          | AC input supply |

### <Heater connector> (CN3)

Model number (MOLEX) : 5566-22A \* Connected to the media heaters (Pre, Print, and After)

The element connection of the media heater is switched automatically according to the input voltage:

AC100-120V Parallel connection  
AC220-240V Serial connection

| PIN | Terminal name | Type    | PIN | Terminal name | Type    |
|-----|---------------|---------|-----|---------------|---------|
| 1   | HEAT3-1A      | HEATER  | 12  | HEAT3-1B      | HEATER  |
| 2   | HEAT3-2A      | HEATER  | 13  | HEAT3-2B      | HEATER  |
| 3   | HEAT3-3A      | HEATER  | 14  | HEAT3-3B      | HEATER  |
| 4   | HEAT3-4A      | HEATER  | 15  | HEAT3-4B      | HEATER  |
| 5   | HEAT3-THA     | THERMAL | 16  | HEAT3-THB     | THERMAL |
| 6   | HEAT2-1A      | HEATER  | 17  | HEAT2-1B      | HEATER  |
| 7   | HEAT2-2A      | HEATER  | 18  | HEAT2-2B      | HEATER  |
| 8   | HEAT2-THA     | THERMAL | 19  | HEAT2-THB     | THERMAL |
| 9   | HEAT1-1A      | HEATER  | 20  | HEAT1-1B      | HEATER  |
| 10  | HEAT1-THB     | HEATER  | 21  | HEAT1-2B      | HEATER  |
| 11  | HEAT1-THA     | THERMAL | 22  | HEAT1-THB     | THERMAL |

**<HEAT ON/OFF> (CN4)**

Model number (MOLEX) : B6B-XH-A (LF) (SN)

| PIN | Terminal name | Type   |
|-----|---------------|--------|
| 1   | HEAT 1 ON     | SIGNAL |
| 2   | 0V            | GND    |
| 3   | HEAT 2 ON     | SIGNAL |
| 4   | 0V            | GND    |
| 5   | HEAT 3 ON     | SIGNAL |
| 6   | 0V            | GND    |

**<DC output connector> (CN5)**

Model number (MOLEX) : 5566-18A

| PIN | Terminal name | Type            | PIN | Terminal name | Type            |
|-----|---------------|-----------------|-----|---------------|-----------------|
| 1   | +42V          | DC power source | 10  | +42V          | DC power source |
| 2   | +24V          | DC power source | 11  | +24V          | DC power source |
| 3   | 0V            | GND             | 12  | 0V            | GND             |
| 4   | 0V            | GND             | 13  | 0V            | GND             |
| 5   | +5V           | DC power source | 14  | +5V           | DC power source |
| 6   | +5SBV         | DC power source | 15  | R/C (ON/OFF)  | Signal input    |
| 7   | +3.3SBV       | DC power source | 16  | +3.3SBV       | DC power source |
| 8   | 0V            | GND             | 17  | 0V            | GND             |
| 9   | 0V            | GND             | 18  | 0V            | GND             |

GND and FG are directly processed in the power supply (pattern)

| Volume No. | Voltage       | Adjustment value |
|------------|---------------|------------------|
| 1          | +3.3SBV - VR1 | 3.28 ~ 3.32      |
| 2          | +5SBV - VR2   | 4.98 ~ 5.02      |
| 3          | +5V - VR4     | 4.98 ~ 5.02      |
| 4          | +24V - none   | -                |
| 5          | +42V - VR3    | 41.0 ~ 41.2      |

# 5-2. Circuit Board Specifications

## 5-2-1. Main PCB

- Board name: Main PCB assembly (E104853)
- The CPU is SH-3 (RISC, 133MHz) made by Hitachi.
- A program for the CPU is written in flash memory. Version up of this program is easily executed on site through I/F.  
The CPU downloads the version up to PRAM to execute writing in the flash memory.
- When receive data is read, The CPU writes the data in picture memory. After execution of required processes by PDC-CTR, the data is transmitted to the HDC with 8 bit width.  
Receiving the data, the HDC creates driving COM signals for head and nozzle data, and transmits each data to the ink slider PCB via HDC FPC cable.
- X, Y-axis motor driving circuit and other IO circuits are also included.

<Block diagram around main PCB>




Fig.5-3

## Main PCB Connector Signals

### <Main PCB connector signals>

| CN No | Pin | Connected to:               | Silk display | Notice                             |
|-------|-----|-----------------------------|--------------|------------------------------------|
| CN1   | 30  | Ink slider PCB              |              | Head, IO signal                    |
| CN2   | 50  | Ink slider PCB              |              | Head signal                        |
| CN3   | 30  | Ink slider PCB              |              | Power source                       |
| CN4   | 30  | Ink slider PCB              |              | COM drive                          |
| CN5   | 6   | Power Supply PCB            |              | Heater control                     |
| CN6   | 6   | Debug monitor               |              | FPGA/CPLD writing                  |
| CN7   | 80  | PRAM PCB                    |              |                                    |
| CN8   | 50  | AUX.                        |              | Extension HDC PCB signal           |
| CN9   | 6   | Debug monitor               |              | FPGA                               |
| CN10  | 8   | AUX.                        |              | Extension HDC PCB power            |
| CN11  | 4   | USB I/F                     |              | USB2.0                             |
| CN12  | 80  | AUX.                        |              | Extension I/F board                |
| CN13  | 5   | AUX.                        |              | Extension I/F power                |
| CN14  | 40  | Station PCB                 |              |                                    |
| CN15  | 30  | X-axis motor relay PCB      |              |                                    |
| CN16  | 28  | X-axis motor relay PCB      |              |                                    |
| CN17  | 10  | Regenerative resistance PCB |              |                                    |
| CN18  | 2   | HDC fan                     |              |                                    |
| CN19  | 2   | AUX.                        |              | Auxiliary                          |
| CN20  | 3   | AUX.                        |              |                                    |
| CN21  | 7   | Thermistor                  |              | Media heater temperature detection |
| CN22  | 4   | Serial debug monitor        |              | Auxiliary                          |
| CN23  | 100 | Debug board                 |              | FW program writing                 |
| CN24  | 18  | Power Supply PCB            |              |                                    |
| CN25  | 5   | Y-axis motor encoder        |              |                                    |
| CN26  | 8   | G/A debug monitor           |              | Auxiliary                          |
| CN27  | 2   | Y-axis motor                |              |                                    |

### 5-2-2. PRAM PCB

- Board name: 128MB PRAM PCB assembly (E103819)
- Inside the electrical box on the main PCB.
- Includes 128 MB picture memory.

### 5-2-3. Station PCB

- Board name: Station PCB assembly (E104854)
- Located inside the right cover on the side panel.
- The pump motor, adsorption fan, paper sensor, Y-original position sensor and other main unit control IOs are connected to it.

## &lt;Station PCB connector signals&gt;

| CN No | Pin | Connected to:  | Silk display | Notice                            |
|-------|-----|--|--------------|-----------------------------------|
| CN1   | 40  | Main PCB   | MAIN         |                                   |
| CN2   | 20  | AUX.   |              | Auxiliary                         |
| CN3   | 24  | Keyboard   | KEY          |                                   |
| CN4   | 4   | Sleep switch   | SLEEP-SW     |                                   |
| CN5   | 2   | Right cover sensor                                     | COVER        |                                   |
| CN6   | 4   | Wash cartridge-ID point of contact PCB, Solenoid valve | WASH         |                                   |
| CN7   | 2   | AUX.   |              |                                   |
| CN8   | 18  | External unit output                                   | OPTION       | Take-up, Exhaust fan, Dryer fan   |
| CN9   | 10  | Adsorption fan   | VACUUM       |                                   |
| CN10  | 4   | Wash cartridge sensor                                  | W-SENS       |                                   |
| CN11  | -   | Skipped  |              |                                   |
| CN12  | 7   | Paper sensor (Rear)                                    | PAPER-F-R    |                                   |
| CN13  | 9   | Clamp sensor, Y-original point sensor                  | CL-Y-CAP     |                                   |
| CN14  | 4   | AUX.   |              |                                   |
| CN15  | 3   | AUX.   |              |                                   |
| CN16  | 3   | AUX.   |              |                                   |
| CN17  | 8   | Wiper unit   | WIPER        | Wiper motor, Wiper original point |
| CN18  | 9   | Pump motor   | PUMP         |                                   |
| CN19  | 6   | AUX.   |              |                                   |

**5-2-4. X-axis motor relay PCB**

- Board name: X-axis motor relay PCB assembly (E104856)
- Located inside the left cover on the back of the ink cartridge unit.
- The solenoids of the 8 ink cartridges, ID, ink near end sensor, cartridge sensor, LED PCB, cover sensor, maintenance cover sensor etc. are connected to it.

**X-axis motor relay PCB connector signals**

## &lt;X-axis motor relay PCB connector signals&gt;

| CN No | Pin | Connect to:          | Silk display | Notice       |
|-------|-----|----------------------|--------------|--------------|
| CN1   | 28  | Main PCB             |              |              |
| CN2   | 20  | LED PCB              |              |              |
| CN3   | 30  | Main PCB             |              |              |
| CN4   | 4   | Ink cartridge ①      | ①            |              |
| CN5   | 4   | Ink cartridge ②      | ②            |              |
| CN6   | 4   | Ink cartridge ③      | ③            |              |
| CN7   | 4   | Ink cartridge ④      | ④            |              |
| CN8   | 4   | Ink cartridge ⑤      | ⑤            |              |
| CN9   | 4   | Ink cartridge ⑥      | ⑥            |              |
| CN10  | 4   | Ink cartridge ⑦      | ⑦            |              |
| CN11  | 4   | Ink cartridge ⑧      | ⑧            |              |
| CN12  | 16  | Ink solenoid ① - ⑧   | VALVE        |              |
| CN13  | 18  | Ink ID ① - ⑧         | INK-ID       |              |
| CN14  | 6   | X-axis motor encoder | X-ENC        |              |
| CN15  | 5   | Not attached         | P-ENC        | Auxiliary    |
| CN16  | 2   | Station cover sensor | COV-ST       |              |
| CN17  | 2   | Left cover sensor    | COV-L        |              |
| CN18  | 3   | AUX.                 | X-DRI        | Auxiliary    |
| CN19  | 6   | Debug monitor        |              | CPLD writing |
| CN20  | 2   | AUX.                 |              | Auxiliary    |
| CN21  | 2   | X-axis motor         | X-MOT        |              |

### 5-2-5. Ink slider PCB

- Board name: Ink slider PCB assembly (E104855)
- Located on the top of the print part slider.
- FFC from HDC is connected to relay signals to head. In addition, the paper width sensor, LED pointer, Y cut cutter, encoder PCB etc. are connected to it.

#### Ink slider PCB Connector Signals

##### < Ink slider PCB connector signals >

| CN No | Pin | Connected to:      | Silk display | Notice                   |
|-------|-----|--------------------|--------------|--------------------------|
| CN1   | 30  | Main PCB           |              | IO control               |
| CN2   | 50  | Main PCB           |              | Head control             |
| CN3   | 30  | Main PCB           |              | Power source             |
| CN4   | 30  | Main PCB           |              | COM waveform             |
| CN5   | 35  | Head               |              |                          |
| CN6   | 31  | Head               |              |                          |
| CN7   | 4   | Paper width sensor | PAPER        |                          |
| CN8   | 6   | AUX.               |              |                          |
| CN9   | 3   | Head height sensor | HEAD-HI      |                          |
| CN10  | 5   | Linear encoder PCB | L-ENC        |                          |
| CN11  | 2   | LED pointer        | LED          |                          |
| CN12  | 3   | Y cut cutter       | CUT          |                          |
| CN13  | 11  | Head memory PCB    | MEM          | Head heater, Head memory |
| CN14  | 6   | Debug connector    | JTAG         |                          |

### 5-2-6. Keyboard PCB

- Board name: Keyboard PCB assembly (E104539)
- It has a LCD with 2 lines of 20 characters and key switches. It is connected to the main PCB with a keyboard cable.

### 5-2-7. Encoder PCB

- Board name: Encoder PCB assembly (E103961)
- There are total 1 boards, namely a board for linear scale placed behind the slider.

### 5-2-8. Take-up PCB

- Board name: Take-up PCB SK assembly (E300413)
- It is used as a relay for the take-up motor and it is connected to the station PCB via an external connector that the user can attach to the take-up unit.

#### Take-up PCB Connector Signals

##### <Take-up PCB connector signals >

| CN No | Pin | Connected to:                    | Silk display | Notice       |
|-------|-----|----------------------------------|--------------|--------------|
| CN1   | 9   | External connector cable         |              | Power source |
| CN2   | 5   | Start, direction changing switch |              |              |
| CN3   | 6   | Take-up motor                    |              |              |

### 5-2-9. Head memory PCB

- Board name: Head memory PCB assembly (E104428)
- Head ID information is stored. Assembled to be integrated into the head.

#### **Head memory PCB connector signals**

---

<Head memory PCB connector signals>


| CN No | Pin | Connected to:        | Silk display | Notice |
|-------|-----|----------------------|--------------|--------|
| CN1   | 3   | Head warm thermistor |              |        |
| CN2   | 11  | Head relay PCB       |              |        |
| CN3   | 2   | Head warm heater     |              |        |
| CN4   | 2   | Head warm heater     |              |        |


### 5-2-10. LED PCB

- Board name: LED PCB assembly (E104988)
- Located inside the left cover on the top and front of the ink cartridge unit.
- The FFC from the X-axis relay PCB is connected to it. It performs display control of the LEDs (green, red) corresponding to each slot of the cartridge.


# 5-3. Electronic block diagram

## 5-3-1. Connection diagram inside main unit





### 5-3-2. Connection diagram outside main unit





## A

|                                   |      |
|-----------------------------------|------|
| ACTION TEST .....                 | 2-32 |
| ADJUST Function .....             | 2-20 |
| DEALER No .....                   | 2-24 |
| DEFAULT SET .....                 | 2-22 |
| EDGE ADJUST .....                 | 2-24 |
| EXCHANGE PARTS .....              | 2-26 |
| HEAD ID .....                     | 2-23 |
| HEAD WASH .....                   | 2-21 |
| MANUALhead WASH .....             | 2-22 |
| MEDIA COMP.2 .....                | 2-25 |
| MOTOR CURRENT .....               | 2-23 |
| POINTER OFFSET .....              | 2-25 |
| SERIAL No .....                   | 2-24 |
| Adjust X-Axis Motor Current ..... | 3-30 |
| Adjust Y-Axis Motor Current ..... | 3-34 |
| Adjustment tools .....            | 1-4  |
| ALL PATTERN .....                 | 2-29 |

## C

|                                    |      |
|------------------------------------|------|
| Capping Assembly .....             | 3-13 |
| Cartridge Control .....            | 2-12 |
| Cartridge LED .....                | 2-11 |
| Caution Label .....                | 0-iv |
| CHECK PATTERN .....                | 2-28 |
| Circuit Board Specifications ..... | 5-6  |
| Encoder PCB .....                  | 5-9  |
| Head memory PCB .....              | 5-10 |
| Ink slider PCB .....               | 5-9  |
| Keyboard PCB .....                 | 5-9  |
| LED PCB .....                      | 5-10 |
| Main PCB .....                     | 5-6  |
| PRAM PCB .....                     | 5-7  |
| Station PCB .....                  | 5-7  |
| Take-up PCB .....                  | 5-9  |
| X-axis motor relay PCB .....       | 5-8  |
| Constitution .....                 | 0-ii |
| Cutter Unit Assembly .....         | 3-45 |

## D

|                           |      |
|---------------------------|------|
| DEALER No .....           | 2-24 |
| DEFAULT SET .....         | 2-22 |
| Download Parameters ..... | 3-22 |

## E

|                                |      |
|--------------------------------|------|
| EDGE ADJUST .....              | 2-24 |
| Electronic block diagram ..... | 5-11 |
| Encoder PCB .....              | 5-9  |
| EXCHANGE PARTS .....           | 2-26 |

## F

|                       |      |
|-----------------------|------|
| F/W update mode ..... | 2-38 |
|-----------------------|------|

## H

|                       |      |
|-----------------------|------|
| HEAD ID .....         | 2-23 |
| Head memory PCB ..... | 5-10 |
| Head Unit .....       | 3-7  |
| HEAD WASH .....       | 2-21 |
| HEATER TEST .....     | 2-31 |

## I

|   |      |
|---|------|
| INK CARTRIDGE .....                       | 2-37 |
| Ink residual quantity control .....       | 2-15 |
| Ink slider PCB .....                      | 5-9  |
| Ink Suction and Discharge Control .....   | 2-17 |
| Ink Supply Control .....                  | 2-7  |
| Ink System .....                          | 2-7  |
| Ink system error monitoring .....         | 2-14 |
| Ink wear-up cleaning (4-color only) ..... | 2-16 |

## K

|                     |      |
|---------------------|------|
| KEYBOARD LED .....  | 2-33 |
| Keyboard PCB .....  | 5-9  |
| KEYBOARD TEST ..... | 2-34 |

## L

|                      |      |
|----------------------|------|
| LCD TEST .....       | 2-34 |
| LED PCB .....        | 5-10 |
| LINEAR ENCODER ..... | 2-37 |

## M

|   |           |
|---|-----------|
| Machine Configuration .....                   | 2-3       |
| Main PCB .....                                | 3-19, 5-6 |
| Maintenance Open Mode .....                   | 2-38      |
| Major Parts for Washing Cartridge Assembly .. | 3-15      |
| MANUALhead WASH .....                         | 2-22      |
| MEDIA COMP.2 .....                            | 2-25      |
| Media Detection .....                         | 2-3       |
| MEMORY CHECK .....                            | 2-35      |
| MOTOR CURRENT .....                           | 2-23      |
| MOTOR TEST .....                              | 2-29      |

## N

|                       |     |
|-----------------------|-----|
| Notes on repair ..... | 1-2 |
|-----------------------|-----|

## O

|                              |      |
|------------------------------|------|
| Operation Flow .....         | 2-40 |
| OPTION .....                 | 2-33 |
| Origin Point Detection ..... | 2-2  |

## P

|                                   |      |
|-----------------------------------|------|
| PAPER SENSOR .....                | 2-34 |
| PARAMETER Function .....          | 2-39 |
| Parameter Up/Down load mode ..... | 2-38 |



POINTER OFFSET ..... 2-25  
 Power Supply ..... 5-4  
 PRAM PCB ..... 5-7  
 Precautions in Maintenance ..... 1-2  
 Preliminary checks ..... 1-3  
 Pump Motor ..... 3-12

## R

Related Documents ..... 0-ii

## S

Safety Symbols ..... 0-iii  
 SENSOR TEST ..... 2-33  
 Sequence at Power-on ..... 2-2  
 SERIAL No ..... 2-24  
 Set Up ..... 2-3  
 SKEW CHECK ..... 2-36  
 Special Key Function ..... 2-38  
     F/W update mode ..... 2-38  
     Maintenance Open Mode ..... 2-38  
     Parameter Up/Down load mode ..... 2-38  
     System Parameter Input Mode ..... 2-39  
 Specifications of the main unit ..... 1-5  
 Station PCB ..... 3-25, 5-7  
 Symbols ..... 0-iii  
 System Parameter Input Mode ..... 2-39

## T

Take-up PCB ..... 5-9  
 TEMPERATURE.CHK ..... 2-36  
 TEST Function ..... 2-27  
     ACTION TEST ..... 2-32  
     ALL PATTERN ..... 2-29  
     CHECK PATTERN ..... 2-28  
     HEATER TEST ..... 2-31  
     INK CARTRIDGE ..... 2-37  
     KEYBOARD LED ..... 2-33  
     KEYBOARD TEST ..... 2-34  
     LCD TEST ..... 2-34  
     LINEAR ENCODER ..... 2-37  
     MEMORY CHECK ..... 2-35  
     MOTOR TEST ..... 2-29  
     OPTION ..... 2-33  
     PAPER SENSOR ..... 2-34  
     SENSOR TEST ..... 2-33  
     SKEW CHECK ..... 2-36  
     TEMPERATURE.CHK ..... 2-36  
     TIMER CHECK ..... 2-34  
     WARMING TEST ..... 2-32  
     WASH CARTRIDGE ..... 2-37  
 TIMER CHECK ..... 2-34  
 Tools required for maintenance work ..... 1-4  
 Tools to be used at disassembly and reassembly . 1-4

## U

Upload Parameters ..... 3-20

## W

WARMING TEST ..... 2-32  
 WASH CARTRIDGE ..... 2-37  
 Wiper Unit ..... 3-42

## X

X-axis Motor ..... 3-28  
 X-axis motor relay PCB ..... 5-8

## Y

Y Drive Belt ..... 3-39  
 Y-axis Motor ..... 3-31



**Mimaki**