

# Knowledge Base

BULLETIN DATE: 6/14/2005  
MODEL: PRO II, PRO II V & VersaCAMM Units  
BULLETIN NUMBER:

AUTHOR:  
Bob

SUBJECT: Service Menu Access

REVISION: Initial  
Release

The following steps will allow you to enter the Service Menu on a PRO II, PRO II V and VersaCAMM series unit. These instructions reflect a change in this procedure. This change was created in Firmware version 6.3 for PRO II/PRO II V and version 5.6 for VersaCAMM series. (FJ-540, CJ-540, SJ-745/645/740/640/540, SC-545/540, SP-540V/300V/300) The SJ-1000/1045 and FJ-Pro series (FJ-600/500/400) will be changed soon.

**Attention! The Service Menu is to be used by Roland DGA Authorized Service Technicians only!**

## Steps:

It is important you complete each step in sequence as directed.

1. 1. The Main Power switch must be on, with the Sub-Power (front panel) switch off.
2. 2. Press the following keys in order :  
UP, LEFT, RIGHT, DOWN, LEFT, DOWN, RIGHT
3. 3. Then, within 5 seconds, press the LEFT, RIGHT and DOWN keys SIMULTANEOUSLY while turning on the Sub-Power switch.
4. 4. If done correctly the unit will turn on and the front panel will display "Service Mode".
5. 5. If the front panel displays "Service Mode is protected", please shut off the Sub-Power switch and try again.

