



Illustration of proper blade length adjustment

When looking down at the blade holder:
***clockwise to increase blade
counter clockwise to decrease***



Media: Such as adhesive vinyl, decal, sticker

backing sheet of media



- The optimal blade length is less than the thickness of the media and backing sheet combined, but more than the thickness of the media. Make sure the blade length is never greater than the combined thickness of the media and its backing sheet.

Always use the **TEST CUT  function of your cutting plotter to test the cutting force/depth of media with backing sheet prior to sending job.*

Kiss cut—Cutting of the media/paper through only to its backing sheet.