

Balance adjustment

- For VT-9600 / VT-9800 Series

1. Open the LEFT side cover (FRONT VIEW)

** remove the tension knobs FIRST by turning it counterclockwise first **

2. In the below pictures, loose these two nuts first, and then you can use the top or bottom screws raise or low the top roller.

** In below pictures, the top roller's position is adjusted by A and C)

a. ** Bring "top roller" down will increase the left pressure.

How to:

Unlock the screw "C" and "A" ;

Adjust bottom screw and bring "top roller" down a little.

** Please adjust a little each time.**

Next, please tighten the top screws C and A.

b. ** While raise "to roller" up will decrease the left side pressure.

How to:

Unlock the screw "C" and "A";

Then first raise the top screw a little so "to roller" have room to go up.

Next adjust the bottom screw and rise 'top roller' a little.

Lock the screw "A" and screw "C".

** Keep in mind that, only adjust left side **
Test after adjustment and re-adjust if necessary.

